





Fast and powerful - the best specs in the history of Memory HiCorders



User-friendly design for accurate and smooth operation Usability Intuitive operation via large 12.1-inch touch screen Blazingly fast, Sampling that never fails Speed High-speed isolation measurement at 200 MS/s

Radically improved time to save measurement data Storage Stress-free user experience

Superior processing capacity so you can save data during Long-term measurement Save data in real time, 32 times faster than conventional market-leading models Recording





Overwhelmingly High-speed Technology

A Revolutionary Approach to Measurement, Recording, and Analysis



Flexible, User-friendly Design

- · Fast and convenient touch screen
- · Operation as smooth as silk



The capacitive touch screen delivers intuitive operability. Select a setting item directly by tapping the screen, and use your fingers to enlarge the part you want to see.

This improved user interface makes setting measurement items for multiple channels easy.

Sampling	Points		Re	cording time		
2 100 MS/s	50 k	Any	50	0 µs		
(10 ns)	200 MS/s	2 MS/s	20 k5/s	200 S/s	2.5/s	1.5/80
Off Off	100 MS/s	1 MS/s	10 kS/s	100 S/s	15/6	
7/	50 MS/s	500 kS/s	5 15/1	50 S/s	30 S/Ivin	
	29 MS/4	200 kS/s	2 85/4	20.5%	12.5/min	
1	10 MS/4	100 kS/1	1 k5/s	10 5/8	t Smin	
/	5 MS/s	50 kS/s	500 5/4	5.5%	2.5/min	

Simply tap the screen to select and change settings.



▲ Tap the screen and use the knob to move the trace cursor as desired.

Video describing the MR6000's intuitive user experience ► https://www.youtube.com/watch?v=z7kFRPsub9U



200 MS/s

Highest Sampling Speed in the Entire Series

- · High-speed isolation measurement at 200 MS/s
- · Up to 16 analog channels & 12-bit ADC resolution

The Hioki Memory HiCorder lineup now includes a powerful input unit that unlocks the full measuring potential of the MR6000.

The High Speed Analog Unit U8976 boasts the highest sampling rate in its entire series, an order of magnitude faster than conventional models, enabling the unit to perform isolated measurement at 200 MS/s.

(200 MS/s measurements can be achieved even if a unit other than the U8976 is connected at the same time. However, the data update rate will not exceed the maximum sampling rate of the other units.)



Max. 16 channels 12-bit ADC resolution

High Speed Analog Unit U8976

Blazingly fast, Sampling that never fails

The High Speed Analog Unit U8976 delivers a 30 MHz frequency band in addition to high-speed sampling at 200 MS/s. It has the performance needed to accurately capture switching waveforms during inverter evaluation testing, an application where high efficiency is critical. Adapted to the Memory HiCorder's direct input feature, it can accept inputs of up to 400 V DC.

Used in combination with the 10:1 Probe 9665

If you encounter issues with the capacitance components of connection cords, use the 10:1 Probe 9665 to reduce the effects on measured waveforms.




 * For more information about frequency deratings, either consult the user manual that comes with the 9665 or contact Hioki.

Safer due to channel-to-channel optical isolation

Connections between analog input channels, and between the input channel and the main unit, are fully isolated. This means that, unlike an oscilloscope, measurements can be made without concern with negative effects from voltage



differences. This is because connections between analog input channels, and between the input channel and the main unit, are fully isolated.



No missed high-speed signals

Capture switching waveforms accurately

Available recording duration 5-second continuous recording at 200 MS/s							
			h: hour	rs, m: minute:	s, s: seconds		
Sampling rate	1 ch	2 ch	3 to 4 ch	5 to 8 ch	9 to 16 ch		
200 MS/s	5 s	2.5 s	1 s	0.5 s	0.25 s		
100 MS/s	10 s	5 s	2 s	1 s	0.5 s		
50 MS/s	20 s	10 s	4 s	2 s	1 s		
20 MS/s	50 s	25 s	10 s	5 s	2.5 s		
10 MS/s	1 m 40 s	50 s	20 s	10 s	5 s		
1 MS/s	16 m 40 s	8 m 20 s	3 m 20 s	1 m 40 s	50 s		
100 kS/s	2 h 46 m 40 s	1 h 23 m 20 s	33 m 20 s	16 m 40 s	8 m 20 s		
slower than above		mo	ore than above)			

(In the case that the internal memory and U8976 are used.)

Video describing measurement at up to 200 MS/s https://www.youtube.com/watch?v=VsEu4FFyaFA



Fastest Save Processing in the Entire Series


- · Radically improved data saving time
- · Stress-free user experience

Transferring very large amounts of data measured over a long period of time used to be very time-consuming.

The MR6000 features a brand new interface and faster internal processing, reducing the time required to save measurement data to media.

For example, a save operation that took 1 minute on the previous model now completes in 2 seconds. This saves you the trouble of waiting for data to be saved and





Video describing radically improved data save time
https://www.youtube.com/watch?v=9glU9XUaH2o



32 ch

h at 1MS/s

Recording

Save Time Reduced to

1/30th Compared to

revious Mode

Longest Continuous Recording in the Entire Series


- · Long-term recording and high-speed sampling in multiple channels
- · Instant analysis of measurement results

You can control the available measurement time by using the real-time save function and an additional storage media.

For long-term recording, we recommend ordering the MR6000 with a built-in high-capacity SSD or HD unit. You can also use a more convenient USB memory stick or SD memory card. All phenomena can be recorded at a high sampling rate over a long period of time.

Saving data directly to your PC

Transfer measurement data directly to your PC by using the FTP sending function or network drive function together with the real-time save function. This makes it easier to observe data after the measuring process.



Available real-time save duration when setting 1 MS/s

Save destination	ns	Sampling rate	Number of channels	Available measurement duration	Maximum sampling rate for real-time save*1
SSD Unit U8332	(256 GB)	1 MS/s	32 ch	Approx. 1 h	20 MS/s
HD Unit U8333	(320 GB)	1 MS/s	16 ch	Approx. 2 h 40 m	10 MS/s
USB Drive Z4006	(16 GB)	1 MS/s	8 ch	Approx. 16 m	5 MS/s*2
SD Memory Card Z4003	(8 GB)	1 MS/s	8 ch	Approx. 8 m	5 MS/s
PC		1 MS/s	8 ch	Depends on PC capacity	5 MS/s

*1: For 2 channels (no settings for 1 channel) *2: When using the USB 3.0 connector

Maximum sampling speeds at which real-time saving is supported

Save destination	Number of channels used						
Save destination	Up to 2 ch	3 to 4 ch	5 to 8 ch	9 to 16 ch	17 to 32 ch		
SSD Unit U8332	20 MS/s	10 MS/s	5 MS/s	2 MS/s	1 MS/s		
HD Unit U8333	10 MS/s	5 MS/s	2 MS/s	1 MS/s	500 kS/s		
USB Drive Z4006 SD Memory Card Z4003 PC	5 MS/s	2 MS/s	1 MS/s	500 kS/s	200 kS/s		

Maximum recording duration for real-time saveing with SSD UNIT U8332 (reference values) d: days, h: hours, m: minutes, s: seconds

Sampling		The	number of channels i	used	
rate	2	4	8	16	32
20 MS/s	53 m 20 s	_	_	_	-
10 MS/s	1 h 46 m 40 s	53 m 20 s	_	_	-
5 MS/s	3 h 33 m 20 s	1 h 46 m 40 s	53 m 20 s	_	_
2 MS/s	8 h 53 m 20 s	4 h 26 m 40 s	2 h 13 m 20 s	1 h 6m 40 s	-
1 MS/s	17 h 46 m 40 s	8 h 53 m 20 s	4 h 26 m 40 s	2 h 13 m 20 s	1 h 6m 40 s
100 kS/s	7 d 9 h 46 m 40 s	3 d 16 h 53 m 20 s	1 d 20 h 26 m 40 s	22 h 13 m 20 s	11 h 6 m 40 s
10 kS/s	74 d 1 h 46 m 40 s	37 d 0 h 53 m 20 s	18 d 12 h 26 m 40 s	9 d 6 h 13 m 20 s	4 d 15 h 6 m 40 s
1 kS/s	more than above	more than above	185 d 4 h 26 m 40 s	92 d 14 h 13 m 20 s	46 d 7 h 6 m 40 s



An Extensive Line of Units for Detecting a Wide Range of Phenomena

Combine multiple units to record a range of phenomena. Use multiple logic units to measure relay ON/OFF signals or PLC (programmable logic controller) signals across up to 128 channels simultaneously. You can also measure temperature by attaching a thermocouple to a temperature unit






Simultaneously measure up to 32 channels

4ch Analog Unit U8975

The U8975 accepts direct input of up to 200 V DC across 4 channels. With a sampling rate of 5 MHz (across a frequency band of 2 MHz), high speed, and 16-bit resolution, it can perform multi-channel, high-speed, and high-resolution measurement.



Simultaneous measurement of multiple locations across 32 channels at 5 MS/s






Record frequency fluctuation and pulse count/integration data

Frequency Unit 8970

Use the Frequency Unit 8970 to record measured waveform frequency, RPM, input pulse integration, duty ratio, and pulse width variations. It can accommodate numerous applications, including measurement of motor RPM, vehicle speed, and power supply frequency fluctuations. Thanks to a maximum input voltage of 400 V DC, it can also directly measure 3-phase circuit carrying up to 200 V.



Time



Direct, high-voltage input without differential


DC 1000 V

High Voltage Unit U8974

probes

The U8974 is ideal for measuring the primary and secondary sides of UPS power supplies and commercial power supply transformers. It can measure high-voltage power lines, including 380 V and 480 V circuits found in many countries. With high-speed sampling at up to 1 MS/s and 16-bit resolution, it can also be used in load rejection testing and switch testing.











Specifically designed for DC voltage measurement with extremely high precision and resolution

Digital Voltmeter Unit MR8990

The MR8990 can measure minuscule fluctuations in sensor output of automobiles and voltage fluctuations in batteries, both at high precision and resolution. It can accommodate maximum input of 500 V DC. This high input impedance allows you to measure the battery voltage without being concerned about leakage current. Additionally, the amount of space taken up by instruments can be reduced by replacing a bench-style DMM with the MR6000. Systems can be simplified by eliminating the need to control multiple instruments.



Battery

Battery pack





Simultaneously measure up to 32 channels at high resolution 4ch Analog Unit U8978

Thanks to four input channels and a high-sensitivity 100 mV f.s. range, the U8978 can measure multiple channels of output from a variety of sensors. The unit is ideal for use in measuring currents of various magnitudes in the development of automobile accessory controls. Utilized in combination with the multi-range Current Probe CT6711, it can measure currents from 1 mA to 50 A.


Observe minuscule currents using high-sensitivity wideband current probes

Current probe lineup

Analyze minuscule current waveforms from low-powerconsumption devices in 100 uA resolution. Record device current consumption waveforms in high resolution over extended periods of time.



Current consumption waveform for a temperature and humidity sensor




During measurement with the CT6711 (10 V/A range)



High-speed sampling lets you accurately measure inrush current

High-Speed Analog Unit U8976

Combine the High-Speed Analog Unit U8976's 30 MHz frequency band with the Current Probe CT6711 to measure inrush currents and minuscule currents.



Power can be supplied from the MR6000.

Power can be supplied to current probes by using the Power Probe Unit Z5021.



Hioki offers a wide range of current probes to suit all frequency band and rated current needs.



3ch 5 MS/s

Single solution for 3-phase current measurement 3ch Current Unit U8977

The U8977 delivers a sampling rate of 5 MS/s, frequency characteristics of 2 MHz, 16-bit A/D resolution, and DC accuracy of 0.3% f.s. to facilitate wideband, high-precision current measurement using Hioki current sensors.

Automatic configuration of sensor scaling values

When you connect a current sensor, the MR6000 will automatically detect the model and set the appropriate scaling value.



Connect sensors directly

Power is supplied from the current unit

Since current sensor power is supplied directly from the current unit, there's no need to provide a sensor power supply.




Compatible with high-precision sensors for measuring large currents

Current sensor lineup

Clamp-type high-accuracy sensors deliver excellent temperature characteristics, allowing highly accurate measurements to be made even in the confined space of a vehicle's engine compartment.




Sensitivity variations of high-accuracy clamp-type sensors caused by temperature



Zero-point stability


Wideband flux gate technology delivers high zero-point stability over extended periods of time.



Hioki offers a wide range of current sensors to suit all frequency band and rated current needs.


CAN/CAN FD Measurement, LIN Measurement

CAN buses carry not only control information, but also sensor information required by the ECU for control purposes. Analog values for sensor input signal quantities such as voltage, strain, temperature, flow rate, RPM, torque, vehicle speed, and vibration can be measured at the same time as these signals.



Capture all data on the CAN and LIN bus during measurement

The MR6000 captures all frame data on the CAN or CAN FD bus and LIN bus during the set recording time. After measurement, you can specify the signals you wish to check and display them on the screen.



Choose signals to display after measuring all bus signals

Vector VN1600 interface family

Simple USB connection

Measure CAN signals without using a special unit. Using a Vector VN1600 interface family product, you can measure CAN signals simply by connecting it to the MR6000's USB port.

No effect on the input units

Principal CAN or LIN signal measurement specifications

 * CAN bus and LIN bus cannot be measured at the same time.

Compatible instruments	Memory HiCorder MR6000/MR6000-01
Compatible interfaces	Vector VN1600 interface family
Number of interfaces that can be connected	Up to 1
Standards	CAN, CAN FD, LIN*
Number of CAN or LIN channels that can be measured	Up to 4*
Number of CAN or LIN signals that can be measured	All frame data on CAN bus or LIN bus
Number of CAN or LIN signals that can be displayed at once	While measuring: 64 preset signals After measuring: 16 signals can be selected and displayed from all recorded data


*Varies with the specifications of the Vector VN1600 product.

*"Vector" refers to the Vector Group, whose parent company is Vector Informatik GmbH. *Hioki is unable to provide Vector products. Please purchase those products separately.


Load to waveform viewers compatibled with MDF format

Analog, logic, CAN, and LIN data measured using the MR6000 are saved in MDF (Measurement Data Format) and can be loaded by any waveform viewer that supports MDF.





Loading an MDF file on Measure Data Analyzer (MDA)



Loading an MDF file on Vector CANape (vSignalyzer)

Load DBC and LDF files with the MR6000

For CAN For LIN

Set the definitions by loading DBC and LDF files on the MR6000. A PC is not required.


File selection									
			Sele	It live line to	add to the si	gral settings			
Signal	10		Start bit	Dit length	Byte circler	Data type	Reto	Other	Check sum
ig184		0		1	Little	(Imignes)	,	- 4	
1988¢		0			Utse	Unsigned	1		
Ng7Dit		0		. 7	Uttle	Unsigned	1		
Siscete		66		1	Little -	Unligned	1		
re		66		10	Utte	Unsigned	1	- 4	
Rate		64	- 23	1	Utile	Unsigned	1		
		(4		18	Uttie	Unsigned	0.1	- 4	
Counter		64	14	,	Little	Unsigned			
institler		11	16	16	Uttle	Unsigned	0.0001	-1	
ine		11		76	Little	Unsigned	0,0001	-1	
ine		10		18	Utile	Unsigned	0.0001	-1	
read:		12		2	Otte:	Unsigned		- 0	
Prok!		12			Little	Unsigned		- 0	

DBC file load screen

Transmit function

For CAN

You can send data configured before measurement to the CAN bus at the start of measurement or when a trigger is activated.



A shortcut key can be assigned to the transmit function

CAN trigger function

For CAN

You can use a CAN signal (frame) as a trigger source. The trigger will be activated when the set CAN signal type and ID is input.

Data frames Remote frames

Set the ID, expressed by a hexadecimal value, as a trigger source.

Error frames

Error frames can also be set as a trigger source.

Hioki offers CAN signal acquisition sensors

For CAN

Non-Contact CAN Sensor SP7001/SP7002

No modification of vehicle cables Acquire signals simply by pinching the cables with the probe.

No effect on the CAN bus or vehicle ECUs

Non-contact sensing technology

Accurate, reliable signal capture Ideal for use in development and evaluation applications


Real-time Waveform Processing Function

Real-time waveform processing

Exclusive MR6000-01 feature

Calculate measurement data during measurement

The MR6000-01 further features powerful technology designed for robust real-time waveform processing. This function performs arithmetic (addition, subtraction, multiplication, and division), differentiation calculations, or integration calculations during the measuring process, letting you check the calculated results via waveforms while measuring or monitor starting from set triggers. Results can be further processed after measurement and saved.



For example, you can calculate a differential waveform for input signals in real time and apply a trigger based on it. You can detect the timing of an input signal's local maximum and minimum values and output an external signal from the TRIG.OUT terminal.

W1	Comment	addition
On	Formula	(CH(1, 1)) + (CH(1, 1))
W2	Comment	sabtraction
On	Formula	(CH(1, 1)) - (CH(1, 1))
w3	Comment	multiplication
On	Formula	(CH(1, 1)) x (CH(1, 1))
W4	Comment	division
On Formula	(CH(1, 1)) / (CH(1, 1))	

Simple setting method


Real-time waveform processing option

Digital filter calculations

Exclusive MR6000-01 feature

Observe clear waveforms without noise

Remove harmonic noise or specific frequency noise from measurement data. Use it to eliminate the noise that cannot be resolved with the standard filter installed in the unit.




Long-term Recording Functionality

In addition to the real-time save function, the MR6000 provides a range of functionality for extended recording.

Envelope function

Observe fluctuations over the long term with high-speed sampling

The system uses the envelope measurement method to record maximum and minimum values at set intervals while performing oversampling at 100 MS/s. The internal memory has a capacity of 1 G-words, which ensures that the measuring process can continue for a long time without any data loss. Save data in real time while measuring.



Over-sampling speed	Recording interval	1 ch		9 to 16 ch
	10 MS/s	50 s		2 s
	1 MS/s	8 m 20 s		20 s
100 MS/s	100 kS/s	1 h 23 m 20 s		3 m 20 s
100 IVIS/S	10 kS/s	13 h 53 m 20 s		33 m 20 s
	1 kS/s	5 d 18 h 53 m 20 s		5 h 33 m 20 s
		more than a	hove	9

^{*}Limitations apply to measurable time when the U8975, U8977, U8978, or MR8990 is in use, and when performing real-time waveform processing.

Dual sampling function

Measure anomalies during extended testing with high-speed sampling

In vibration testing, it's necessary to record comprehensive test data for several hours. At the same time, it's necessary to capture areas of the waveform where anomalies occur with high-speed sampling for analysis once measurement is complete. The dual sampling function is useful in such situations.


(1) Record the entire trend waveform

Use the envelope function to record comprehensive test data for several hours.



(2) Check details with the instantaneous waveform

Anomalies occurring during the test will be captured with high-speed sampling based on triggers that have been set up in advance. By tapping on a trigger mark's number, you can display the instantaneous waveform for the anomaly that occurred at that waveform area.



Tap to enlarge the anomaly waveform

Trend waveform

Verify that no anomalies occurred during extended testing


No trigger marks

If no instantaneous waveform triggers activated, there were no anomalies. By viewing the trend waveform, you can not only verify that no anomalies occurred, but also check whether the device under test operated properly.

Trigger Function


Triggers that detect targeted events

Set triggers on any channel to record data whenever an event occurs. Triggers can be set for all channels.



Setting multiple triggers for a single channel


Set up to 4 triggers for a single channel. If, for instance, you set the glitch, level, window-in, and window-out triggers for the same input waveform, that waveform is monitored according to the set trigger conditions



Display Functions

Numerical display function

This function is effective for checking the status before and during measurement.



Displays the measured value and the waveform at the same time.

Sheet function (display group)

The instrument supports 3-, 6-, and 9-segment screen displays, allowing measurement results for 3-phase circuits to be displayed efficiently.



the sheet button

6-screen display 9-screen display



FFT display






8-screen display



2-screen display


Scroll function

You can use the scroll function to check the waveform as if viewing it on paper.



Zoom function

The zoom function allows you to display all measurement waveforms on a single screen in the manner of an oscilloscope and to view desired locations in greater detail.



X-Y display

Waveform Search Function


Easily search for waveforms in huge volumes of measurement data

Memory HiCorder Concierge function

The Memory HiCorder Concierge function automatically calculates the characteristics of a reference waveform set by the customer and then searches all measured data while identifying waveforms that do not resemble the reference waveform as anomalous waveforms

This drastically reduces the amount of time required to search for anomalies by eliminating the need to scroll through measured waveforms and checking them visually. Additionally, this function is ideal for situations where it is difficult to set the right triggers before

measuring because the nature of potential anomalies cannot be predicted.



Peak search

Search for the maximum value, minimum value, local maxima, or local minima in all of the measured data, and mark the search point in the waveform.

Trigger search

Set trigger conditions for all of the measured data after measurement to search for points where the conditions are fulfilled, even if no triggers were set before the measuring process.


Jump

Jump to an event mark you made while measuring, to the cursor position on the display, or to the measured data of a specified time.

Waveform Generation Function

Achieving the dual role of generation and recording with a single unit


The arbitrary waveform generation function and waveform measurement function are realized by one Memory HiCoder.



Waveform output as expected ARBITRARY WAVEFORM GENERATOR UNIT U8793

Waveform observation while changing test conditions, such as changing the signal type, amplitude and frequency, and programming various waveforms to output them sequentially, can be made easier.

Output waveform example



Waveform Maker Software included

After you install the included SF8000 Waveform Maker software on MR6000 or your computer, you can create waveforms easily by either entering them directly or by entering the formulas behind them. You can also quickly add noise and multiply waveforms.




Anomaly Simulation

Reproduce and output the observed waveforms without modification. When resolving problems observed during research or development, you can reproduce such problems for efficient testing. For example, you could output actual waveforms recorded from a car without modification, and then use them for standalone testing. You can also generate isolated output of up to 15 V while varying the signal's amplitude and frequency without using a generator or amplifier, which is traditionally necessary. For example, you can create a power waveform such as power supply dips, instantaneous interruptions, and voltage fluctuations to use in an immunity test (to cause malfunctions in equipment caused by power supply harmonics).



Reproducibility testing



Measurement of abnormal waveform in actual vehicles



Max. 15 V output + amplifier



Reproduce and output anomalous waveforms

Supported by MR6000 Ver.4.00





Supported by MR6000 Ver.4.00 PULSE OUTPUT HIOKI MR8791 PULSE GENERATOR UNIT THORAL 2507



DC/sine wave output WAVEFORM GENERATOR UNIT MR8790

- \cdot 4 channels \cdot DC and up to 20 kHz sine wave signal output
- \cdot Signal output ±10 V, 5 mA


Pulse/pattern/logic/open collector output PULSE GENERATOR UNIT MR8791

- · 8 channels · Pulse waveform signal output
- \cdot Output mode (pulse output, pattern output, logic output, open collector output)

Power measurement functionality

Simultaneous measurement of a motor inverter's mechanical signals and power

The MR6000 can perform power measurement, which provides an effective means of evaluating the mechanical operation and electrical characteristics of equipment such as motor inverters. The instrument's power calculation function can display power values that change in small amounts of time on a cycle-by-cycle basis.






When a Hioki high-precision current sensor is directly connected using the 3CH Current Unit U8977, the instrument automatically detects the sensor. (There is a limit on how many sensors can be connected.)

When measuring high voltages, the instrument can supply power to up to eight Differential Probe 9322 units using the Power Cord 9248 and the Probe Power Unit Z5021.

Display of voltage, current, and power trends


When measuring voltage and current after configuring power calculation settings, the instrument automatically performs waveform calculations and displays power values. In addition, it can display calculation results after measurement if you configure the power calculation settings.



Example display of power calculation results

Cycle-by-cycle calculations

The instrument performs calculation processing for each cycle, defined as the interval from one zero-cross point to the next zero-cross point, based on the waveform chosen as the reference channel.



Power calculations based on detected cycles

Simple settings screen

A dedicated screen makes it easy to configure settings for power calculations, including wiring method and voltage and current channels.





No need to register detailed power equations

Rotation angle measurement functionality

Measurement of resolver rotation angle

Using the waveform calculation function, the instrument acquires three channels of data (resolver excitation signal, $\cos \theta$, and $\sin \theta$) and generates a trend display for the motor's rotation angle.







Example of resolver signal measurement

Measurement of rotary encoder rotation angle

Using the waveform calculation function, the instrument acquires the A, B, and Z pulse signals from the rotary encoder and generates a trend display for the motor's rotation angle.

*Only incremental method is available. Absolute method is not available.





Example of rotary encoder rotation angle waveform

Applications


Time Measurement

By performing numerical calculations on measured waveforms, you can perform analyses using numerical parameters. Not only analog channels and logic channels, but also results of the real-time waveform calculation function can be used in this calculations.

Calculating switching times measured using logic channels (t1, t2, t3, T)

You can calculate time differences by applying numerical calculations to signals measured with logic channels.






Calculate the time difference T (s) at which waveforms A and B cross the specified level when either rising or falling.

Time difference T = Waveform B (time at which levels cross) - waveform A (time at which levels cross)

Reference channel (waveform A) calculation settings: Level Slope Calculation target channel (waveform B) calculation settings: Level Slope



Measurement waveforms and desired time differences


Trigger time	12:00.0
No. 1 time difference (t1)	1.50 s
No. 2 time difference (t2)	2.00 s
No. 3 time difference (t3)	1.00 s
No. 4 time difference (T)	4.50 s

Example above: numerical calculation results

Calculating the time that elapses until a reading falls from the maximum value to a defined level (e.g. 50 V) after a capacitor is charged during capacitor charge/discharge testing

You can calculate the defined value by calculating the time at which the maximum value occurs and the time at which the specified level occurs using numerical calculations and then performing your desired arithmetic operations.






- 1. Calculate the time to the maximum value (A) Calculation settings: Time to maximum value
- 2. Calculate the time at the specified level (B) Calculation settings: Level Slope Filter
- 3. Subtract (A) from (B)

Calculation settings:


Calculation No. 1

arithmetic operation

Calculation No. 2



Time to maximum value Calculate the time (s) from the trigger time until the maximum value. If the maximum value occurs at 2 or more points, the initial value will be treated



Specified level time

The Memory HiCorder searches for the point at which the previously set level is crossed. It then calculates the time between the start of the calculation range to that level crossing point


Four arithmetic operations

Select the result of the numerical calculation and apply your desired arithmetic operations (addition, subtraction, multiplication, or division).

Calculating the motor inrush starting current time (t1)

You can derive the desired time by calculating the burst width using numerical calculations.





Calculate the time at which the burst signal is output

Calculate the duration of an oscillating signal, for example the inrush current when a motor starts operating, as the burst width.

Calculation settings:

Filter **Statistics** Burst end filter Window (upper limit, lower limit)

Available calculation functions

Numerical calculations Perform up to 32 of 34 available calculations simultaneously during measurement.


Average value	Minimum value	Rise time	Specified level time
RMS value	Time-to-minimum value	Fall time	Specified time level
Peak-to-peak value	Period	Area value	Pulse width
Maximum value	Frequency	X-Y area value	Duty ratio
Time-to-maximum value	Standard deviation		

Pulse count	High level	Overshoot	Burst width
Arithmetic operation	Low level	Undershoot	Integration values
Time difference	Median value	+ Width	X-Y waveform angle
Phase difference	Amplitude	– Width	CAN statistics

Applications Motor Torque and Vibration Measurement

Using a strain-gage-type converter or acceleration sensor, you can measure torque and vibration during motor operation. Discover unpredicted frequency components by using FFT calculations to perform a frequency analysis.

Record torque and vibration during motor operation



Simultaneous measurement and instantaneous analysis

The torque sensor (strain-gage-type converter) is connected to the Strain Unit U8969 to measure torque.


An acceleration sensor affixed to the chassis on which the motor is mounted, is connected to the Charge Unit U8979 to measure vibrations being transferred to the chassis.

The MR6000's FFT calculation function can be used to perform a frequency analysis of torque and vibration signals.

Available calculation functions

FFT calculation function


The MR6000 can analyze 8 phenomena simultaneously per measurement. Multiple FFT analyses of signals input from different channels let you investigate the frequency components that appeared for each channel at a single point in time. Similarly, conduct a variety of analyses for a single signal simultaneously.



FFT calculation 4-split screen


FFT analysis directly from the measured data

Perform FFT analysis from measured data. Simply touch the screen to specify the starting point for analysis, while simultaneously viewing the calculation results.



Chronological order + FFT calculation screen

Products used




^{*1} Strain-gage-type converter
*2 Charge-output-type with built-in
pre-amp (IEPE type)
(For more information about
sensors, please contact the sensor
manufacturer.)

Applications

Measurement of Dynamic Motor Characteristics

By using the X-Y display function with RPM on the X-axis, you can analyze fluctuations in torque, motor power, motor efficiency, and inverter output power for each RPM level

Record fluctuations in various parameters from motor's start to stop



All-in-one measurement + pinpoint analysis

The signal from the torque sensor (Strain-gage-type converter) is measured with the Strain Unit U8969. Output from the motor's encoder (e.g. A-phase) is connected to the Frequency Unit 8970 to measure RPM

The 3-phase inverter's voltage is measured using the 4ch Analog Unit U8978 and the Differential Probe 9322.

The 3-phase current is measured using the 3ch Current Unit U8977 and current sensors. Motor power, motor efficiency, and inverter output power are calculated after measurement using high-speed waveform processing, and the results are displayed using the instrument's X-Y display function.


Compositing over the specified X-Y interval

You can choose locations and generate an X-Y display of fluctuating waveforms from motor start to motor stop.

Available display functions

X-Y display function

The MR6000 provides an extensive range of X-Y displays for captured waveforms, including an X-Y 1-screen display, X-Y 2-screen display, X-Y 4-screen display, and time series display + X-Y 2-screen display. The ability to use the X-Y display for waveform processing results as well as input signals from measurement units means that you can perform a broad range of analyses.



4-screen X-Y display

XY waveform angle and area values

You can use the numerical calculation function on the X-Y display. Calculate XY waveform angle and area values using the numerical calculation function while viewing the X-Y display.

Calculate regression lines for the XY composite and then calculate the slope

$$SLOPE = \frac{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x}) \cdot (y_i - \overline{y})}{\displaystyle\sum_{i=1}^{n} (x_i - \overline{x})^2} \\ \sum_{i=1}^{n} (x_i - \overline{x})^2 \\ \text{xi: ith data point for X-axis channel} \\ \theta = \arctan\left(SLOPE\right) \cdot \frac{180}{\pi} \left[^{\circ} \right] \\ \overline{x} \text{ Average value for X-axis channel} \\ \overline{y} \text{ Average value for Y-axis channel} \\ \overline{y} \text{$$

Calculate the area of the XY composite

X-Y area value (coordinate method) with multiple curves

manufacturers



 $S = n \times S0$ S: Area value n: Number of curves

Start point, end point

Products used



- *1 The 4ch Analog Unit U8975 can be used when measuring voltages of 100 V AC or less.
- *2 Strain-gage-type converter (for more information about the sensor, please contact the sensor manufacturer.)

Software



Load data measured with the MR6000/ MR6000-01 onto a PC to display waveforms and perform calculations

Intuitive operation

Waveform processing


FFT calculations


Utilize functionality similar to that provided by the MR6000 on a PC, including numerical calculations, waveform processing, and FFT calculations. (Some restrictions apply.)

Supported models	MR6000, MR6000-01
Supported operating system	Windows 10 (64-bit) For other system requirements, please see the user manual.
Availability	Free download from the Hioki website

Waveform display zoom

Zoom each axis in or out by spinning the mouse's scroll wheel while placing the cursor over either the left or bottom of the screen.






Functionality similar to the MR6000


me as instrument iunctionality and usability

You can display data, change settings, perform calculations, and save data in the MR6000 Viewer.





Ideal for creating reports

Copy a screenshot of the waveform screen to the clipboard.




Register waveform formulas and perform calculations





Wave Processor 9335 (sold separately)

The 9335 provides waveform display, processing, and printing functionality.



Overview of 9335 specifications

System requirements	Windows 10/8/7 (32-bit/64-bit)
Functionality	Display functionality: Waveform display, X-Y display, cursor function, etc. File loading: Loadable data formats (.mem, .rec, .rms, .pow); The maximum loadable file is the maximum size of the Memory HiCorder being used. (The loadable file size is also dependent on the maximum size that can be saved by the PC being used.) Data conversion: Conversion to CSV format, batch conversion of multiple files, etc.
Printing	Printing functionality: Save print image file (in .emf format) 1, 2, 4, 8, or 16 graphs; 2, 4, 8, or 16 rows, 1, 2, or 4 X-Y graphs; preview; hard copy

Comparison with other Hioki software

Software	MR6000 Viewer	Wave Processor 9335
Waveform screen	Yes	Yes
Trace cursor	Yes	Yes
Saving	.csv, .txt, .set, .bmp, .png, .jpeg, binary, .flt	.csv, .txt
Settings	Yes*1	No
Printing	No	Screen image, detailed printing
Numerical calculations	Yes	Yes
Waveform processing	Yes	No
FFT calculations	Yes	No
X-Y display	Yes	Yes
Supported operating systems	Windows 10 (64-bit)	Windows 10, Windows 8, Windows 7 (32-bit, 64-bit)
Price	Free	Varies with region

^{*1} After loading waveform data, you can edit settings and create settings files.



Bringing Field Measuring Results to Your PC Simultaneous Observation of Data from Multiple Instruments

Data collection

Real-time performance Batch display and saving

GENNECT One lets you display and save data in real time on a PC during measurement. It also serves as a useful tool in measurement applications that include other instruments.

Supported models	MR6000, MR6000-01, etc.
Supported operating system	Windows 7 (32-bit / 64-bit), Windows 8.1 (32-bit / 64-bit) Windows 10 (32-bit / 64-bit), Windows 11
Availability	Free download from the Hioki website

LAN remote control function

Connect to instruments via a LAN.


Change instrument settings and control operation, for example to start or stop measurement.



Example remote control screen

Simultaneous, real-time observation

GENNECT One lets you display data from multiple instruments together and in real time in list or graph form.




(up to 512 parameters)

Graph display (up to 32 parameters)

List display (up to 32 parameters)

Commercially available software

FAMOS



- · More than 400 calculation processing variables
- · Easy report creation functionality Download a free MR6000 import filter free of charge from Hioki's website.

FlexPro




- · High-speed search and processing of large volumes of data
- · Share analysis templates inside your company

NI DIAdem



- · Functionality ranging from searching and loading of data to analyzing and creating of reports
- · Dialog-based interface

OS-2000



- \cdot Freely edit large data that cannot be handled by Excel
- · Simultaneously display the waveforms which have different frequencies

Control scripts and drivers

On Hioki's website, search for "MR6000" > "Downloads" > "Drivers, Firmware & Software" to find downloadable drivers.


MATLAB

Available scripts allow you to directly load waveform data measured and saved using the MR6000's memory function, while control scripts let you start and stop measurement, acquire measurement data, and configure measurement settings.





LabVIEW

An available driver lets you control the MR6000 and acquire measurement data. The driver was created using LabVIEW 2009 sp1, and it has been confirmed to operate with LabVIEW 2017.



Multifunctional Interface







Onen or close the top panel of the main unit Z4006 USB DRIVE installable

Only 6 keys in total New recorder design

Use the touch screen to configure all the basic settings.

Display

12.1-inch capacitive touch screen TFT color LCD display

USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

SAVE button

For displaying the manual save dialog box

Shortcut button 1

For registering frequently used settings

Shortcut button 2

For registering frequently used settings

Rotary knob X

For moving the tracing cursor and scrolling or zooming the waveform in and out

Rotary knob Y

For changing the position and zooming the waveform in and out

START button

To begin the measuring process

STOP button

For importing the set recording length and stopping the measuring process

Power button

For turning the power on or off

USB 2.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

USB 3.0 connector × 2

For connecting a USB memory stick, USB mouse, or USB keyboard

SD MEMORY CARD slot For inserting SD memory cards

Output terminal for probe compensation signals For outputting 10:1 or 100:1 PROBE compensation signals

KEY LOCK

For disabling the touch screen and buttons

For carrying the device

1000 BASE-T connector

For connecting to a network via LAN cable

DVI terminal

For outputting the screen display

External sampling terminal

For inputting various external sampling signals

External control terminal

For inputting various external signals to control the device

Dedicated power supply terminal for current sensors

For supplying power to current sensors (option)

Various units

Install input units appropriate for the measurement target


Air inlet

For reducing the internal temperature

Media box

For USB 3.0 connectors (USB memory sticks only)

Operability and visibility suited for a variety of work environments



Ergonomical operating angle

Our search for a touch screen with the best operability and visibility angle led us to develop retractable feet that maximize those two important attributes. Tilting the MR6000 with the feet reduces the strain on your wrists when you use the device on a desk, and keeps your line of sight at a natural level.

Convenient long handle Robust design

Easy handling

The rubber handle boasts excellent grip and makes it easy to carry the device with either one or both hands. The grips on either side of the device can also be used to lift it with both hands.

Compared to conventional models 1/2 size See compared to 8861-50

Space-saving size

We have achieved a design that is compact while still delivering blazing fast processing speeds by using thermal liquid analysis to optimally position the air inlets, heating components, and cooling fans.

Sleek design

The beveled corners of the Memory HiCorder's body gives the device a compact and sleek look. This simple and refined appearance is sure to be a strong addition to the creative environment of any R&D workspace.

MR6000 MEMORY

71 25

fos@distrame.fr - www.distrame.fr

Product Specifications

Basic Specifications (Accuracy guaranteed for	1 year)	weform recording		
	Normal: Regular waveform recording Envelope: Periodically recording maximum and minimum values			
Recording method	*Envelope setting no	ot available with external sampling		
		ords waveforms at a sampling speed different from the speed during envelope measurement.		
		2 channels (with 4ch ANALOG UNIT U8975/U8978) 3 channels (LOGIC UNIT 8973)		
No. of channels	*Common GND for t	the logic probe input connector and main unit		
	CAN/LIN: Up to 64 of *CAN/LIN bus data			
Maximum sampling		els at the same time) (with HIGH SPEED ANALOG UNIT		
rate	U8976) External sampling (10 MS/s)		
Memory capacity	1 G-words			
Operating environment Operating temperature	Indoors, pollution de	egree 2, altitude up to 2000 m (6562.20 ft)		
and humidity range	0°C to 40°C (32°F to	0 104°F), 80% RH or less (non-condensing)		
Storage temperature and humidity range	-10°C to 50°C (14°F	to 122°F), 80% RH or less (non-condensing)		
Compliance standards	Safety: EN61010, EN	MC EN61326		
		e: 100 V to 240 V AC (consider ±10% voltage fluctuations		
Power supply	for rated supply volt Rated power supply	age) r frequency: 50 Hz / 60 Hz		
	Anticipated transien	it overvoltage: 2500 V		
Max. power consumption Clock	300 VA	-year correcting 24-hour clock		
Backup battery life		t 23°C (73°F)) for clock and settings		
PC interface (overview)	LAN, USB, SD, SAT.	A, monitor		
External dimensions	 	235 mm (9.25 in.) H x 154.8 mm (6.09 in.) D (excluding protrusions		
Mass	6.5 kg (229.3 oz.) (n 6.7 kg (236.3 oz.) (v	vith Z5021, U8332, or U8333 installed)		
		with HIGH SPEED ANALOG UNIT U8976 installed) art Manual (booklet, CD-R), operating precautions (booklet),		
Accessories	application disk (CD-F	R), Instruction Manual (detailed edition) (CD-R), Instruction Manu		
Accuracy	(MR6000-01 exclusive	e functions edition) (CD-R), blank panel (blank slot only)		
Accuracy guarantee	Tamparatus	miditures 20, 0000 , 500 /7005 , 005 , 000 , 511 , 1		
conditions		umidity range: 23°C ±5°C (73°F ±9°F), 80% RH or less		
Time axis accuracy	±0.0005%			
Display Display type	12.1 inch XGA TFT	color LCD (1024 x 768 dots) with capacitive touch screen		
LAN Interface				
Compatibility specifications	IEEE 802.3 Ethernet	: 1000BASE-T, 100BASE-TX, 10BASE-T		
Functions	l	ITTP, Network drive, e-mail sending function		
Connector Maximum cable length	RJ-45 100 m (328.11 ft.)			
USB interface	(02011111)			
0	LICE 2.0 sempliont.	· 2. LICD 2.0 semplicat v. 4		
Compatibility specifications	USB 3.0 Compilant	x 3, USB 2.0 compliant x 4		
Compatibility specifications Host	Connector: Series A	receptacle		
Host	Connector: Series A	receptacle : Keyboard, mouse, USB memory stick		
Host Available options	Connector: Series A Connected devices:	receptacle : Keyboard, mouse, USB memory stick		
Available options SD card slot Compatibility specifications	Connector: Series A Connected devices: Z4006 USB MEMOR	receptacle Key/board, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards)		
Host Available options SD card slot Compatibility specifications Available options	Connector: Series A Connected devices: Z4006 USB MEMOR	receptacle Keyboard, mouse, USB memory stick PY STICK (16 GB)		
Host Available options SD card slot Compatibility specifications Available options SATA interface	Connector: Series A Connected devices: Z4006 USB MEMOR	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output	Connector: Series A Connected devices Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2	A receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) EX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 x 768 (XGA)	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) EX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 x 768 (XGA) *Dual-link not support	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) EX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 x 768 (XGA) *Dual-link not support	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) EX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) "Dual-link not support cerminal SMB 10 V DC	A receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 x 768 (XGA) *Dual-link not support criminal SMB 10 V DC 2.5 V to 10 V for hig	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KE Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD sta USB MEMORY STICE Serial ATA Revision U8332 SSD UNIT (20 DVI-1 Digital output* and a 1024 x 768 (XGA) "Dual-link not suppoterminal SMB SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more during terminal connections of the suppose of t	A receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency	Connector: Series A Connected devices Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 x 768 (XGA) *Dual-link not supporterminal SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more during 10 MHz External sampling c	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level In g high periods, 50 ns or more during low periods lock input		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions	Connector: Series A Connected devices: Z4006 USB MEMOF STICE SERIES AND STICE SERIES AND	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control tel	Connector: Series A Connected devices Z4006 USB MEMOF Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not suppor erminal SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more during 10 MHz External sampling c Rising, falling, rising	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level In g high periods, 50 ns or more during low periods lock input		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control tel	Connector: Series A Connected devices: Z4006 USB MEMOF STICE SERIES AND STICE SERIES AND	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level In g high periods, 50 ns or more during low periods lock input		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control tel	Connector: Series A Connected devices. Z4006 USB MEMORY STICE Serial ATA Revision. U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 x 768 (XGA) *Dual-link not supporterminal SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more during 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Input voltage	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) Index (10 CARD Z4003 (8 GB)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Input rotlage Fesponse pulse width Maximum input frequency Functions External control ter Terminal block	Connector: Series A Connected devices: Z4006 USB MEMOF STICE SERIES AND STICE SERIES AND	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) EX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) Inalog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input g falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during ligh periods, 50 ms or more during low periods		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD status B MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) "Dual-link not support of the status between	A receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input a falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during low period 200 ms or greater		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Input rotlage Fesponse pulse width Maximum input frequency Functions External control ter Terminal block	Connector: Series A Connected devices: Z4006 USB MEMOF STICE SERIES AND STICE SERIES AND	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KE Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) Inalog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input g falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during low periods, 50 ms or more during low periods		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block	Connector: Series A Connected devices: Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the property of the	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input a falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Sesponse pulse width Maximum input frequency Functions External control ter Terminal block	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD status USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 x 768 (XGA) **Dual-link not support of the state of the sta	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input a falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices. Z4006 USB MEMOF STIC USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 USB MEMORY STIC USB MEMORY S	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input a falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices. Z4006 USB MEMOF STIC USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) *Dual-link not suppoterninal SMB 10 V DC 2.5 V to 10 V for high summer serial sampling c Rising, falling, rising minals Push-button type Maximum input voltage Input voltage Input voltage Input voltage Input voltage Input voltage Suppose pulse width Pulse interval Number of terminals Functions Output type Maximum input voltage Maximum input voltage Mumber of terminals Functions Output type Output voltage Maximum input voltage	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error.		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices: Z4006 USB MEMOF STIC Compliant with SD status BMEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) "Dual-link not support of the status by the s	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) IX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input g & falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices. Z4006 USB MEMOF STICE SERIES A COMPLIANT STICE SERIES AND STICE SERIES AND SERIES	Areceptacle Keyboard, mouse, USB memory stick Reyboard, mouse, USB memory stick RY STICK (16 GB) Mards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices: Z4006 USB MEMORY STIC USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) "Dual-link not support of the property of the	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) ndards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input g falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC External trigger filter OFF: 1 ms or more during high		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices. Z4006 USB MEMOF STICE SERIES A COMPLIANT STICE SERIES AND STICE SERIES AND SERIES	Areceptacle Keyboard, mouse, USB memory stick Reyboard, mouse, USB memory stick RY STICK (16 GB) Mards x 1 (compatible with SD, SDHC, SDXC memory cards) KX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input is falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input	Connector: Series A Connected devices. Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not suppresent of the serial SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more durin 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output voltage Maximum input voltage Response pulse input voltage Maximum input voltage Maximum input voltage Maximum input voltage Number of terminals Functions Maximum input voltage External trigger filter Response pulse	Areceptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) KE Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input g & falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during high periods		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices. Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not suppresent of the serial SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more durin 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output voltage Maximum input voltage Response pulse input voltage Maximum input voltage Maximum input voltage Maximum input voltage Number of terminals Functions Maximum input voltage External trigger filter Response pulse	Areceptacle Keyboard, mouse, USB memory stick RYSTICK (16 GB) Mards x 1 (compatible with SD, SDHC, SDXC memory cards) KX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during high periods Rilsing, falling, rising & falling (user-selectable)		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices. Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not suppresent of the serial SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more durin 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output voltage Maximum input voltage Response pulse input voltage Maximum input voltage Maximum input voltage Maximum input voltage Number of terminals Functions Maximum input voltage External trigger filter Response pulse	Areceptacle Keyboard, mouse, USB memory stick Reyboard, mouse, USB memory stick RY STICK (16 GB) Mards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input is falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ws or more during high periods, 2.5 ms or more during low periods Rising, falling, rising & falling (user-selectable) Rising, Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V).		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices. Z4006 USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not suppresent of the serial SMB 10 V DC 2.5 V to 10 V for hig 50 ns or more durin 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Response pulse width Pulse interval Number of terminals Functions Output voltage Maximum input voltage Response pulse input voltage Maximum input voltage Maximum input voltage Maximum input voltage Number of terminals Functions Maximum input voltage External trigger filter Response pulse	Areceptacle Keyboard, mouse, USB memory stick TY STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) IX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter OFF: 25 ms or more during high periods, 2 us or more during low periods Rising, falling, rising & falling (user-selectable) Rising: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage rises from low (0 V to 0.8 V) or when a		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type	Connector: Series A Connected devices: Z4006 USB MEMOP Compliant with SD status B MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the state	Areceptacle Keyboard, mouse, USB memory stick Ry STICK (16 GB) Indards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted In level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input a falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during low periods Rising, falling, rising & falling (user-selectable) Rising: Triggering occurs when the voltage falls from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage falls from		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices: Z4006 USB MEMOP Compliant with SD status B MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the state	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) andards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 to 10 V) V to 10 V V O V V O V V O V V V V V V V V V V		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices: Z4006 USB MEMOP Compliant with SD status B MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) *Dual-link not support of the state	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) andards x 1 (compatible with SD, SDHC, SDXC memory cards) CX Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW; 2.5 ms or more during high periods, 2.5 ms or more during low periods Rising, falling, rising & falling (user-selectable) Rising: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V) Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to low (V to 0.8 V) or when a terminal short circuit occurs. When the trigger timing is set to [START&STOP], the edge to be used can be chosen between rising, falling,		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Response pulse width Maximum input frequency Functions External control ter Terminal block External input External output	Connector: Series A Connected devices: Z4006 USB MEMOF Compliant with SD status B MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) **Dual-link not support of the state	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) andards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OS: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OS: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OS: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OS: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OS: 2.5 ms or more during high periods, 2.5 to 10 V). Palling: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to 10 w (0 V to 0.8 V) or when a terminal short circuit occurs: When the trigger timing is set to [START] and [STOP] Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input voltage Terminal block External control ter Terminal block External input External input	Connector: Series A Connected devices: Z4006 USB MEMOF STIC Compliant with SD status BMEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-1 Digital output* and a 1024 × 768 (XGA) "Dual-link not supporterninal SMB 10 V DC 2.5 V to 10 V for high Sons or more during 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Input voltage Input voltage Maximum input voltage External trigger filter Response pulse width Functions Output type Output voltage Maximum input voltage External trigger filter Response pulse width	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) andards x 1 (compatible with SD, SDHC, SDXC memory cards) K Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low period 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of error busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2 us or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter ON: 2.5 ms or more during high periods, 2.5 to 10 V). Falling: Triggering occurs when the voltage rises from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to low (0 V to 0.8 V) or high (2.5 V to 10 V). Palling: Triggering occurs when the voltage talls from high (2.5 V to 10 V). Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V). Palling: Triggering occurs when the voltage talls from high (2.5 V to 10 V).		
Host Available options SD card slot Compatibility specifications Available options SATA interface Compatibility specifications Available options Monitor output Connector Output type External sampling Connector Maximum input voltage Input voltage Input voltage Input roltage Terminal block External input External input External input External input External output	Connector: Series A Connected devices. Z4006 USB MEMOF STIC Compliant with SD sta USB MEMORY STIC Serial ATA Revision U8332 SSD UNIT (2 DVI-I Digital output* and a 1024 × 768 (XGA) **Dual-link not suppoterminal SMB 10 V DC 2.5 V to 10 V for hig SO Ns or more during 10 MHz External sampling c Rising, falling, rising minals Push-button type Maximum input voltage Input voltage Response pulse width Pulse interval Number of terminals Functions Output type Output voltage Maximum input voltage Response pulse width Functions Maximum input voltage Maximum input voltage External trigger filter Response pulse width Functions Maximum input voltage Functions Maximum input voltage Maximum input voltage External trigger filter Response pulse width Functions	receptacle Keyboard, mouse, USB memory stick RY STICK (16 GB) andards x 1 (compatible with SD, SDHC, SDXC memory cards) CK Z4001 (2 GB), SD MEMORY CARD Z4003 (8 GB) 3.0 compliant x 1 56 GB), U8333 HD UNIT (320 GB) analog output for external display orted h level, 0 V to 0.8 V for low level g high periods, 50 ns or more during low periods lock input 8 falling (user-selectable) 10 V DC 2.5 V to 10 V for high level, 0 V to 0.8 V for low level 50 ms or more during high periods, 50 ms or more during low periods 200 ms or greater 2 START, STOP, START/STOP, SAVE, ABORT, event Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level 50 V DC, 50 mA, 200 mW 2 Judgment (PASS), judgment (FAIL), occurrence of errors busy, trigger standby 10 V DC ON / OFF External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OFF: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OFF: 1 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 ms or more during low periods External trigger filter OW: 2.5 ms or more during high periods, 2.5 to 10 V) to 10 w (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage isses from low (0 V to 0.8 V) to high (2.5 V to 10 V). Falling: Triggering occurs when the voltage falls from high (2.5 V to 10 V) to 10 w (0 V to 0.8 V) or when a terminal short circuit occurs: When the trigger timing is set to [START] and [STOP] Open drain output (active low, with 5 V voltage output) 4.0 V to 5.0 V for high level, 0 V to 0.5 V for low level		

Output signals	0 V to 5 V ±10%, 1 k	Hz ±1% square waves		
Functions		00:1 PROBE 9666 correction		
Dedicated power si	upply terminal for	current sensor with PROBE POWER UNIT Z5021 installed)		
	1	with PROBE POWER UNIT Z5021 installed)		
Number of terminals Output voltage	± 12 V ± 0.5 V DC			
Trigger *Not available		a function is used		
Trigger type	Digital comparison to			
Trigger conditions		n for trigger sources and interval trigger		
		me waveform processing		
		OP is selected: Up to 32 channels iggers can be set for each analog channel.		
	*Up to 4 logic trigg	gers can be set for each logic probe. gers can be set for each real-time waveform processing channel.		
T. day	When START&STO	P is selected: Up to 16 channels / group		
Trigger source		nannels / group (Up to 2 channels per unit can be selected.) robes / group (Up to 2 probes per unit can be selected.)		
		n processing: Up to 16 calculations / group pes from each group can be set for each analog channel.		
	*Up to 2 logic trig	gers from each group can be set for each logic probe.		
	External trigger The free run function	is activated if all trigger sources are turned off.		
	Level trigger	Triggering occurs when the set level rises (falls).		
	Voltage drop trigger	Triggering occurs when peak voltage drops below the set level. (For a 50 Hz / 60 Hz commercial power supply only)		
		*1, *2, *3		
	Window trigger	Sets the upper and lower limit for trigger level. Triggering occurs when leaving (OUT) or entering (IN) the area		
		*1		
	Period trigger	Sets the period reference value and cycle range. Triggering occurs when the rising (falling) reference value period is measured and determined to be outside or within the cycle range. *1. *2. *3		
Analog triggers		Sets the reference value and pulse width (glitch width).		
	Glitch trigger	Triggering occurs if the value is below the set pulse widt from rising or falling of the reference value.		
		*1, *Not available with MR8990, *3		
		Specifying events (1 to 4000) Counts the number of times conditions were fulfilled for each trigger		
	Specifying events	source. Triggering occurs when the set number of times is reached		
		*Not available when the trigger conditions are set to AND *1: Disabled when sampling rate is set to 200 MS/s.		
		*2: Not available with MR8990 or 8970		
Logic trigger	Pattern trigger using	*3: Not available with envelope setting		
Forcible trigger		iggering can be prioritized over all trigger sources.)		
		ggered when receiving a specific data frame, error frame,		
CAN trigger	or remote frame. When a data frame is chosen, the instrument can be triggered by comparing			
	between bits in specific byte positions.			
Interval trigger		t specified measuring intervals (hours, minutes, or seconds) as are fulfilled when the measuring process starts.		
	Afterwards, the trigg	er conditions are met at the set measuring intervals.		
Trigger filter	Normal	OFF, 10, 20, 50, 100, 150, 200, 250, 500, 1000, 2000, 5000, 10,000 samples		
	Envelope	OFF, 1 ms, 10 ms		
Trigger level setting resolution	1 LSB			
Pre-trigger	time for pre-trigger	lue set in 1% steps available), displaying the recording		
Post-trigger	0% to 40%, displayir	ng the recording time for post-trigger		
Trigger priority	ON / OFF			
Trigger mark	Displays trigger mar START, STOP, STAR	ks for the positions where triggers are set.		
Trigger timing Waveform monitoring	-	rm monitor in the trigger standby state. (The display can		
display	be turned off.)			
Waveform screen				
	Time-domain waveform representation	1, 2, 3, 4, 6, 8, 9, 16 screens (Up to 64 channels can be displayed on each sheet.) (Every channel can be set to be displayed on multiple sheets.)		
		1, 2, 4 screens, combination of time-series waveforms		
Display format	XY composite	and XY (2 screens) (Unsettable when envelope is enabled)		
	waveform display	(Up to eight XY composite waveforms can be set)		
		(Multiple sheets can display the same composite waveforms)		
	FFT display	1, 2, 4 screens, combination of time-series waveforms and FFT representation (1, 2, 4 screens)		
Sheet function	Up to 16 sheets	*The display format can be selected for each sheet.		
Zoom display	ON / OFF (Waveforms	are displayed in chronological order in the top part of the		
	waveform screen, whe	reas the zoomed waveforms are displayed in the bottom part.)		
Full screen display		over the entire waveform screen. ay position can be defined by specifying a waveform		
Grid anchoring mode	display magnification	n and a zero-level position.		
Waveform display	Waveform color	Fixed colors (32 colors)		
	Interpolation Variable display	Linear Always enabled when grid anchoring mode is disabled.		
	Waveform display			
	magnification	100x to 1/10x (available when grid anchoring mode is enabled		
	Waveform display zerodisplay position	In increments of 1 percent point (available when grid anchoring mode is enabled)		
	Vernier	Adjustable input waveform		
	Grid	(Adjustment range: 50% to 250% of the input) OFF / ON		
	Logic display width	Wide / Standard / Narrow		
	Waveform inversion	Displays waveforms upside down.		
		*Not available with 8967, 8970, and 8973		
Enlarge / Reduce	Allows you to adjust grid anchoring mode	the zoom ratio as necessary by pinching in or out. (when e is disabled)		
Mountains annalling	Scroll left or right by	swiping the screen and scroll back while measuring.		
Waveform scrolling				
Roll display mode	The drawing start po	latest data by following the measuring process. sition (left or right edge) can be selected. displayed when the overlay function is turned on.		
	The drawing start po *The roll cannot be o	sition (left or right edge) can be selected.		

Cursor Gauge	Up to 8 cursors can be displayed. *Displays potential, time from trigger, time difference between cursors, and potential difference.	Saving	SD MEMORY CARD	Z4001 (2 GB), Z4003 (8 GB)
Gauge Up to 8 gauge Specifying segments Segment cur- Specifies the Jump Tap the scree Input available during the measure Use the start button or external ing Settling screen 200 M, 100 h 500 k, 200 k, 500, 200 L to 10 h 500 k, 200 k 500, 200 L to 10 h 10 M, 5 M, 2 500 k, 200 k 50 k, 200 k 500 k, 200 k 500 k, 200 k 500 k, 200 k 500 k, 200 k 50 k, 2	Unito 8 cursors can be displayed	-	USB MEMORY STICK SSD	
Specifying segments Jump Tap the scree Input available during the measur Use the start button or external input available during the measur Use the start button or external inguitable for the same available for the same availa	*Displays potential and potential difference.	Save destination	HDD	U8332 SSD UNIT (256 GB) U8333 HD UNIT (320 GB)
went mark vent vent mark vent on Mark vent mark ven	Up to 8 gauges can be displayed.	-	Sending to FTP	PC with a LAN connection
Input available during the measur Use the start button or external ing etiting screen 200 M, 100 N	5 Specilies the calculation range, saving range, and search range.	_	Sending e-mails Network drive	Send files via e-mail to specified address LAN-connected drive
ampling rate ampling rate Dual sampling For real-time saving The numbers in parentheses above so Definition of the number of channels (16 channels), 20 connection for the consultation of the channels (16 channels). 28436400 (2 channels). 28436400 (Tap the screen to jump to the specified location. Idable during the measuring process (up to 10000 marks)	Backup	destination can be s	on is FTP, network drive or email transmission, an alterna set for use in the event communications fail. , or USB drive (user-selectable)
Normal 200 M, 100 h 500 k, 200 k, 500, 200, 100 h The speed from 100 MS;	art button or external input terminal for input.	File format	FAT, FAT32, NTFS,	exFAT
Ambility of the control of the contr	200 M, 100 M, 50 M, 20 M, 10 M, 5 M, 2 M, 1 M 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k	Filename Processing identical		Japanese input or is added to the file name to be saved. position: preceding, following, and automatically added to
external sam Up to 10 MH 10 M, 5 M, 2 500 k, 200 k, 500, 200, 10 30, 12, 6, 2, "Calculation "Oversamplii" Instantaneou	500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s] *The speed for real-time waveform processing can be set from 100 MS/s.	filenames	file names (user-sel ON / OFF *Automatically save	ectable) es the data obtained for the recording length at the end of
taximum recording from real-time saving save destired for the save "USB memor of channels used." Invelope Envelope Envelope Dual sampling Dual sampling Dual sampling Dual sampling For real-time saving "The values in () indicate the number of channels used." "In envelope for the save "USB memor on 3.0 connected for the save "USB memor on 3.0 connected (16 channels) says says says says says says says sa	External sampling: Depending on the input signal of the external sampling terminal Up to 10 MHz	Auto saving	*When using memo	ot supported. available when real-time saving is selected. ry segmentation, measurement of the next block can star
Instantaneou 100 M, 50 M	10 M, 5 M, 2 M, 1 M 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k 500, 200, 100, 50, 20, 10, 5, 2, 1 [5/s]		ON / OFF	nitations on sampling rate and recording length apply.)
ampling rate Dual sampling For real-time saving For real-time saving For real-time saving The values in () indicate the number of channels used. Dual sampling Dual	30, 12, 6, 2, 1 [S/min] *Calculation speed for maximum and minimum values *Oversampling rate: 100 MS/s	Real-time saving	*Saves the waveford directly to the save	m data (binary) obtained during the measuring process destination. *The auto saving function is not available. Files are divided for approx. every 512 MB of data. Divides a file at specified intervals.
ampling rate Dual sampling Dual sampling Dual sampling Dual sampling The sampling minimum valual "The instrum set for instan Maximum avalual "The instrum set for instan in channels used. For real-time saving For real-time saving The values in () indicate the number of channels used. Built-in presett channels, 200 kS/s (3 "Guaranteed for the save "USB memon 3.0 connected for the save "USB memon 3.0 connected (8 channels), 200 kS/s (6 "Guaranteed for the save "USB memon 3.0 connected (8 channels), 200 kS/s (6 "Guaranteed (8 channels), 200 kS/s (6 "Setting is pose (8 channels), 200 kS/s (8 channels), 200 kS/	[Instantaneous waveform] 100 M, 50 M, 20 M, 10 M, 5 M, 2 M, 1 M 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k 500, 200, 100, 50, 20, 10, 5, 2, 1 [5/s]	Deleting and saving	free space left on th	by the oldest creation dates and saves data when there is ne specified media at the save destination. aving and real-time saving.
ampling rate Dual sampling sampling rate [Trend wavef 10 M, 5 M, 2 500 k, 200 k, 500, 200, 10 30, 12, 6, 2, 2 The samplin minimum valual the instrument of the save destire (4 channel saving 4 channels used) For real-time saving *The values in () indicate the number of channels used. *The values in () indicate the number of channels used. *The values in () indicate the number of channels used. *The values in () indicate the number of channels used. *The values in () indicate the number of channels (20 kS/s) (3 "Guarantee of the save "USB memor 3.0 connected (4 channels 50 kS/s) (5 "Felting is possed (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Point] [Arbitrary recording in the save "USB memor 3.0 connected (8 channels), 20 [Poi	*Selectable from sampling rate 10 times faster than trend waveform		Settings data	.SET Binary format (.MEM, .REC, .FLT, .MDF, MF4)
aximum recording ngth Envelope Env		ı	Waveform data	Text format (.TXT, .CSV) COMTRADE format (.CFG, .DAT) Divided saving (.IDX), memory segmentation (.SEQ), of
So, 12, 6, 2, 17he samplin minimum valid in Instrum set for instant Maximum as et for instant Maximum as et for instant in MSis (32 For real-time saving	10 M, 5 M, 2 M, 1 M 500 k, 200 k, 100 k, 50 k, 20 k, 10 k, 5 k, 2 k, 1 k 500, 200, 100, 50, 20, 10, 5, 2, 1 [S/s]	Turner of accordance	Index Displayed images	sampling batch save (.R_M) .BMP, .PNG, .JPG
For real-time saving For real-time saving For real-time saving The values in () indicate the number of channels used. For real-time saving The values in () indicate the number of channels used. For real-time saving Normal Real-time saving For real-time saving Built-in preset channels, 200 KS/s (3 "Guaranteed for the save "USB memo 3.0 connected (6 channels, 200 KS/s (3 "Guaranteed for the save "USB memo 3.0 connected (6 channels, 200 KS/s (3 "Guaranteed for the save "USB memo 3.0 connected (6 channels, 200 KS/s (3 "Setting is pos (6 channels), 200 Point) For real-time saving For real-time saving For real-time saving Trend wave 1/2 of maxim or less For real-time saving Trend wave 1/2 of maxim or less For real-time saving Trend wave 1/2 of maxim or less For real-time saving To real-time saving Potential time with two input channel Consider that use of one input channel consider that 2. For modules with three or four input -1. Consider that use of either CH3 or occupies one channel. 2. Consider that use of either CH3 or occupies one channel. 3. Real-time waveform calculation Consider that one expression occupies work channels. 3. Real-time waveform calculation occupies two channels. 3. Real-time waveform calculation occupies two channels. 3. Real-time waveform calculation occupies work channels. 4. Consider that use of either CH3 or occupies work channels. 5. Real-time waveform calculation occupies work channels. 6. Consider that one expression occupies work channels. 6. Consider that	30, 12, 6, 2, 1 [S/min] *The sampling rate represents a rate at which maximum and	Types of saved data	Numerical calculation results Startup	
Maximum av Save destri	minimum values are calculated. *The instrument performs oversampling at the sampling rate set for instantaneous waveforms.		CAN frame data	Binary format (.CLG), text format (.TXT, .CSV)
For real-time saving "The values in () indicate the number of channels used. "Guaranteed for the save "USB memo 3.0 connect to the save "USB memo 3.0 connect () fic channels, 20 [Built-in preset channels, 20 [Point] [Arbitrary reco () fic channels, 20 [Arbitrary reco () fic channels () channels [Point] [Arbitrary reco () fic channels 288435400 () "Setting is pos [Instantaneo Less than have to the norm for	Maximum available sampling rate	-	Arbitrary waveform data Generation program data	
For real-time saving "The values in () indicate the number of channels used. Solo kS/s (3 Guaranteed for the save "USB memor 3.0 connects channels, 20 [Point] [Point] [Arbitrary recording with the properties of the save "USB memor 3.0 connects (8 channels, 20 [Point] [Arbitrary recording with the properties of the save "USB memor 3.0 connects (8 channels, 20 [Point] [Arbitrary recording for the save "USB memor 3.0 connects (8 channels, 20 [Point] [Arbitrary recording for the save "I (8 channels) (8 channels) [Point] [Arbitrary recording for the save "I (8 channels) [Point] [Arbitrary recording for the save "I (8 channels) [Point] [Arbitrary recording for the save "I (8 channels) [Point] [Poin	[Save destination: SSD] 20 MS/s (2 channels), 10 MS/s (4 channels), 5 MS/s (8 channels), 2 MS/s (16 channels),		Pulse pattern data	.PLS (when Model MR8791 is installed)
aximum recording and the company of the number of channels used. **The values in () indicate the number of channels used. **Guaranteed for the save "USB memon 3.0 connects channels, 20 [Point] Normal Built-in presets channels, 20 [Point] Normal [Authrary record (16 channels) \$36879900 (2 "Settling is poss [Built-in presets (8 channels), 20 [Point] Envelope [Envelope [Authrary record (16 channels) \$36845400 (3 "Settling is poss (8 channels), 20 [Point] Envelope [Envelope [Authrary record (16 channels), 20 [Authrary record (16 channels), 20 [Authrary record (16 channels), 20 (3 "Settling is poss (8 channels), 20 [Authrary record (16 channels), 20 (4 channels), 20 [Authrary record (16 channels), 20 (4 channels), 20 [Authrary record (16 channels), 20 [Authrary record (20 [Authrar		Saving channels	Select a channel from	om all the channels available or from the displayed chan orm data.
indicate the number of channels used. sending wit (4 channels 200 kS/s (3 "Guaranteed for the save "USB memon 3.0 connecte for the save "USB memon 3.0 connecte (16 channels), 20 [Point] Normal [Arbitrary reco (16 channels), 20 [Point] [Arbitrary reco (16 channels), 539870900 (2 Setting is pos 20 channel), 12 [Point] Envelope [Built-in preset (8 channels), 6 channels, 12 [Point] [Arbitrary reco (16 channels), 6 channels, 13 [Point] [Arbitrary reco (16 channels), 6 channels, 14 [Point] [Arbitrary reco (16 channels), 6 channels, 15 [Point] [Arbitrary reco (16 channels), 6 channels, 16 [Point] [Arbitrary reco (16 channels), 6 channels, 16 [Point] [Arbitrary reco (16 channels), 6 channels, 17 [Point] [Arbitrary reco (16 channels), 6 channels, 18 [Point] [Arbitrary reco (16 channels), 18 [Point] [(4 channels), 2 MS/s (8 channels), 1 MS/s (16 channels), 500 kS/s (32 channels), 200 kS/s (64 channels)	Culled data saving	Waveform data (tex (from 2 to 1000) bef	t format) is culled according to the specified culling values fore saving.
channels used. 200 kS/s (3 "Guaranteed for the save e "USB memoro 3.0 connecte for the save e "USB memoro 3.0 connecte channels, 200 kG/s (2 "Guaranteed (3 kG Ammels), 2 kG Ammels), 2 kG Ammels, 2	e sending via FTP, Network drive] 5 MS/s (2 channels), 2 MS/s	File division *Real-time saving and	Types of saved data Binary format	Division method OFF / Every 16 MB of data / Every 32 MB of data / Every 64 MB of d
for the save. "USB memod 3.0 connected channels, so properties of the save." Normal [Built-in presett channels, so properties of the save." Row of the save of the save of the save. See than he for the normal properties of the save		memory segmentation excluded	Text format	OFF / Every 60,000 points of data / Every 1,000,000 points of data
Aximum recording aximum recording gritting the control of the cont	for the save destination. *USB memory data guaranteed only when using the USB	Specifying files	New files / Existing fi	OFF / By the calculation number iles *Enabled when numerical calculation results are saved
Normal [Point] [Arbitrary record (16 channels, \$388709001, \$2 Setting, is possible to the property of the channel (16 channels), channel (17 channels), channel (18 channels), channel (18 channels), channel (18 channels), channel (18 channels), channels, ch	[Built-in presets] 20 M (32 channels), 50 M (16 channels), 100 M (8	-	Instant saving	ate a new file or add data to an existing file when starting to measu Press the SAVE button to save data to a save destination, un a filename, and with saving settings that have been pre-set.
(16 channels 538870900 (2 "Setting is pos 538870900 (2 "Setting is pos 16 "Setting is pos 16 "Built-in preset (8 channels), channel [Poi (Arbitrary recoording 16 channels 288435400 (2 "Setting is pos 288435400 (3 "Setting is pos 28843540 (3 "Setting is pos 288	channels), 200 M (4 channels), 500 M (2 channels), 1 G (1 channel) [Point] [Arbitrary recording length] 33554400 (32 channels), 67108800	SAVE button operation	Saving range	Select the full range or a specific segment. *Enabled only when data is saved with the SAVE key.
Built-in preset (8 channels), channel] [Poi	(16 channels), 134217700 (8 channels), 268435400 (4 channels), 536870900 (2 channels), 1073741800 (1 channel) [Point]	Loading data	LCD MEMORY CARE	
(8 channels), channel) [Poi [Arbitrary reco (16 channels)] aximum recording gith Dual sampling Dual sampling Instantaneo Less than he for the norms Trend wave 1/2 of maxim or less Determined as destination, fill	*Setting is possible in units of 100 points. [Built-in presets] 10 M (32 channels), 20 M (16 channels), 50 M	-	USB MEMORY STICK	2 Z4001 (2 GB), Z4003 (8 GB) C Z4006 (16 GB)
aximum recording pulses and pulse	(8 channels), 100 M (4 channels), 200 M (2 channels), 500 M (1 channel) [Point] [Arbitrary recording length] 16777200 (32 channels), 33554400 (16 channels), 67108800 (8 channels), 134217700 (4 channels),	Loading source	HDD Network drive Setting data (.SET)	U8332 SSD UNIT (256 GB) U8333 HD UNIT (320 GB) LAN-connected drive
Dual sampling Less than he for the norms in the norms or less than he for the norms or less in the norms or less	268435400 (2 channels), 536870900 (1 channel) [Point] *Setting is possible in units of 100 points.	-	Waveform data: Bin	ary format (.MEM, .REC, .MDF, .MF4) (.IDX), memory division (.SEQ), dual-sampling batch saving (.R
aximum recording ngth For real-time saving Determined at destination, fill of the saving s	[Instantaneous waveform] Less than half of the maximum recording length provided for the normal method	Types of loaded data	Start-up (STARTUP. Arbitrary waveform	
For real-time saving Determined at destination, fill "The numbers in parentheses above s Definition of the number of channels t 1. For modules with two input channel Consider that use of one input channel For Model MR8990 only, consider that 2. For modules with three of four input channel For Model MR8990 only, consider that 2. For modules with three of four input 1-1. Consider that use of either CH3 or occupies one channel. 2. Consider that use of either CH3 or occupies one channel. Using channels under the combined occupies two channels. 3. Real-time waveform calculation. Consider that one expression occupie "When either any one of Model U8975 waveform calculation is used, each for a sampling rate of 10 MS/s or slow expeated seasurements. Single, repeated, specified number seat and the number of times cannot aveform monitoring function. Displayed on the channel setting a "Conversion ratio and offset / 2-point "Model: Select a model to configue "Automatic detection and automatics of the channel comments." Title comments, channel comments. Calculation formulas. 23 formulas. Calculation targets. Measuremer Calculation targets. Title comments, channel comments. Calculation targets. All Massuremer Calculation targets. The 8973 and Calculation update and the part of the season of the channel comments. Calculation targets. The 8973 and "Up to 8 calculation update and "Up to 8 calculation "Up to 16 calculation "Up to 16 calculation".	1/2 of maximum recording length listed under "Envelope"	Automatic loading of	Pulse pattern data (Divided waveform files	.PLS) (when Model MR8791 is installed) (in binary format) can be loaded seamlessly.
"The numbers in parentheses above s Definition of the number of channels t 1. For modules with two input channel Consider that use of one input channel For Model MR8990 only, consider that 2. For modules with three or four input 1. Consider that use of either CH1 or occupies one channel. 2. For modules with three or four input 1. Consider that use of either CH1 or occupies no channel. 2. Consider that use of either CH3 or occupies no channel. Using channels under the combined of occupies two channels. 3. Real-time waveform calculation Consider that one expression occupie "When either any one of Model U8975 waveform calculation is used, each r for a sampling rate of 10 MS's or slow expeated Single, repeated, specified number set and the number of times cannot played on the channel setting: "Automatic detection and automatic setting" "Automatic detection and automatic setting" "Automatic detection and automatic setting" Calculation formulas 32 formulas Calculation targets Calculation targets Title comments, channel comments Calculation targets Calculation update To M/ 1 M/ "The 8973 and Typ to 8 calc "Up to 16 calculation to 16	me saving Determined according to the amount of free space in the save destination, file system, and number of measurement channels	divided files	memory, the instrument	djacent to the end of a waveform saved in the instrument's internal t will additionally load files, leaving the waveform in the internal men
1. For modules with two input channel Consider that use of one input channel For Model MR8990 only, consider that as of one input channel For Model MR8990 only, consider that 2. For modules with three or four input 1. Consider that use of either CH1 or occupies one channel. 2. Consider that use of either CH3 or occupies one channel. 2. Consider that use of either CH3 or occupies two channels. 3. Real-time waveform calculation Consider that one expression occupie 'When either any one of Model U8975 waveform calculation is used, each for a sampling rate of 10 MS/s or slow sequence of the saturation of the channel setting and the number of times cannot set and the number of times cannot wellow monitoring function 2. Conversion ratio and offset / 2-point 'Model: Select a model to configure 'Automatic detection and automatic 'Automatic detection and automatic 'Automatic detection and automatic Channel numbers and channel comments. 3. Calculation targets Syria 3. 25 formulas 4. Calculation targets Syria 3. 32 formulas 4. Calculation update 1. (20 M / 1 M /	ers in parentheses above show the number of channels to be used.	Numerical calculat Maximum number of	1	
For Model MR8990 only, consider that 2. For modules with three or four input -1. Consider that use of either CH1 or occupies one channel2. Consider that use of either CH3 or occupies one channel2. Consider that use of either CH3 or occupies one channel. Using channels under the combined occupies two channels3. Real-time waveform calculation Consider that one expression occupie "When either any one of Model U8975 waveform calculation is used, each r for a sampling rate of 10 MS/s or slow set and the number of times cannot set and the number of times cannot weform monitoring function Displayed on the channel setting set and the number of times cannot weform monitoring function Conversion ratio and offset / 2-point "Model: Select a model to configue "Automatic detection and automatic set and channel comments." Title comments, channel comments Channel numbers and channel comments. Calculation formulas 32 formulas Measuremer Calculation targets 8371,8972, "The 8933 and "Up to 8 calculation update rate" "Up to 16 calculation to 16 calculation update and "Up to 16 calculation to 16 calculation update and "Up to 16 calculation targets" "The 16 calculation update and "Up to 16 calculation update a	ules with two input channels	calculations Calculation range	32 items x Measure Full range / Specifie	
occupies one channel. 2- Consider that use of either CH3 or occupies one channel. Using channels under the combined occupies two channels. 3. Real-time waveform calculation. Consider that one expression occupie "When either any one of Model U8975 waveform aclulation is used, each for a sampling rate of 10 MS/s or slow separated. Single, repeated, specified number set and the number of times cannot be set of the combined of the combined to the channel setting set of the combined that is the combined to the channel setting set of the channel	nat use or one input channel occupies one channel. MR8990 only, consider that use of one input channel occupies two channels. ules with three or four input channels (Models U8975, U8977, U8978) er that use of either CH1 or CH2 or simultaneous use of CH1 and CH2	Calculation range	Turrange / opeome	Peak to peak value, maximum value, minimum value, high-level, latelevel, average value, effective (RMS) value, standard deviation, rise time (*), fall time (*), frequency (*), period (*), duty ratio (*), pulse co
3. Real-time waveform calculation Consider that one expression occupie "When either any one of Model U8975 waveform calculation is used, each r for a sampling rate of 10 MS/s or slov epeated Single, repeated, specified number set and the number of times cannot aveform monitoring function Displayed on the channel setting: "Model: Select a model to configu "Automatic detection and automatics "Automatic detection and automatics Calculation formulas 32 formulas Calculation targets Calculation targets Measuremen Calculation targets igital filter Calculation update rate Calculation update 10 M / 1 M / "Up to 8 calc "UP to 16 calc "UP to 16 calc "UP to 16 calc "UP to 16 calculation and calculation accurate to the service of the servic	one channel. r that use of either CH3 or CH4 or simultaneous use of CH3 and CH4 one channel. nnels under the combined condition of those provided in items -1. and -2.	Calculation items	Normal	area value, X-Y area value, time difference (*), phase difference (*) time to maximum value, time to minimum value, specified level tim specified time level, pulse width (*), four arithmetic operations, me value, amplitude, integration value, burst width (*), X-Y waveform
"When either any one of Model U8975 waveform calculation is used, each r for a sampling rate of 10 MS/s or slow set and the number of times cannot aveform monitoring function aveform monitoring function Displayed on the channel setting: "Model: Select a model to configue "Automatic detection and automatics of the channel comments." Calculation formulas: Calculation formulas: Calculation targets: Wheaver and the number of times cannot move the channel comments. Calculation targets: "Title comments, channel comments." Calculation targets: "The 8973 and the model users are set of the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8973 and the provided that the channel comments." Calculation targets: "The 8974 and the channel comments."	e waveform calculation			angle, overshoot, undershoot, +width (*), -width, CAN statistics * Statistical functions (start, average, maximum, minimum, count) avail
peated saverements Single, repeated, specified number easurements at and the number of times cannot aveform monitoring function Displayed on the channel setting staling "Model: Select a model to configuration and offset / 2-point and offset / 2-point and offset / 2-point and setting staling "Model: Select a model to configuration and automatic staling and channel comments of the	er any one of Model U8975, U8977, U8978, and MR8990 or the real-time a calculation is used, each maximum recording length reduces to half or less	Numerical judgment	Targeted waveforms Judgment settings	Analog channels, logic channels, real-time wavef processing channels, waveform processing results ON / OFF
set and the number of times cannot aveform monitoring function Displayed on the channel setting staling Conversion ratio and offset / 2-point and offset / 2-point and offset / 2-point and offset / 2-point and automatic staling "Model: Select a model to configure "Automatic detection and automatic staling" and comments Title comments, channel comments Calculation formulas 32 formulas Measuremer 8971, 6972, 1 "The 8973 and 10 M / 1 M /	pling rate of 10 MS/s or slower. Deated, specified number of times *Repeated measurements cannot be	-	Stop conditions	PASS, FAIL, PASS&FAIL
Conversion ratio and offset / 2-point 'Model: Select a model to configu 'Automatic detection and automate Title comments, channel comments Channel numbers and channel comments Calculation formulas Calculation targets Galculation targets Galculation update Galculation update rate Calculation update 'Up to 16 cal 'Up to 16 cal	e number of times cannot be specified for real-time saving.		*Not available with	envelope setting, not available simultaneously with real-time savi
waling "Model: Select a model to configure "Automatic detection and automatics" Title comments, channel comments Channel numbers and channel comments. Calculation formulas 32 formulas Calculation targets 8971, 8972, the 8973 and channel comments of the selection of the select	d on the channel setting screen on ratio and offset / 2-point input / Model / Output rate / dB / Rating	Maximum number of calculations	16 formulas	
Channel numbers and channel comments. Calculation formulas 32 formulas Calculation targets 8971, 8972, 1716 8973 and Galculation update rate 100 /	elect a model to configure the scaling settings automatically.	Calculation range Standard operator	Full range / Specifie +, -, x, ÷	ed segments
Calculation formulas 32 formulas Calculation targets 4971, 8972, U 17he 8973 and 10 M / 1 M / Up to 8 calculation targets 4000-01 only			Absolute value, expon derivative, integral, se	ent, common logarithm, moving average, derivative, second cond integral, square root, cubic root, parallel move (translation
Calculation targets 8971, 8972, \		- Calculation items	PLC shift, sine, cosine FIR (LPF, HPF, BPF, B	, tangent, arc sine, arc cosine, arc tangent, 2-argument arc tang SF), IIR (LPF, HPF, BPF, BSF), half-wave average, half-wave per
igital filter Calculation update rate 10 M / 1 M / rate 10 m / 10 to 8 calculation update rate 10 m / 1 m / 10 to 16 calculation update rate 10 m / 1 m / 10 to 16 calculation update rate 10 m / 1 m / 10 to 16 calculation update rate 10 m / 1 m / 10 to 16 calculation update rate 10 m / 1 m / 10 to 16 calculation update rate 10 m / 10 m / 10 to 16 calculation update rate 10 m / 1	Measurement channels in 8966, 8967, 8968, U8969, 8970 n targets 8971, 8972, U8974, U8975, U8976, U8977, U8978, U8979 "The 8973 and MR8990 measurement channels are not applicable.		frequency, full-wave R value (*), minimum val	nalf-wave RMS value, full-wave average, fullwave period, full-wav iMS value, polarity, binarization, CAN/LIN average (*), maximum ue (*), level at specified time (*), Resolver, ABZ encoder an be specified as constants in expressions.
MR6000-01 only "Up to 16 ca	on update 10 M / 1 M / 100 k / 10 k / 1 k / 100 / 10 / 1 [S/s] *Up to 8 calculations can be set for 10 MS/s.		Maximum number of	
Carodiation	*Up to 16 calculations can be set for 1 MS/s. Calculation 10 MS/s 1 MS/s 100 kS/s 10 kS/s or less	-	Supported wiring methods	(3P3W), 3-phase/3-wire (3-voltage/3-current method) (3V3A), 3-phase/4-wire (3P4W)
Calculation delay update rate Calculation	update rate 10 MS/s 1 MS/s 100 KS/s 10 KS/s 01 less	Power calculations	Measurement method method	Zero-cross synchronization method
Filter types FIR (LPF / Hi moving aver.	Salculation 0.2 of 5 us 20 us Calculation update		Calculation items	Voltage RMS value, voltage average value, voltage simple me value, current RMS value, current average value, current simp

		ponential average (the number of averaging can be				
Averaging function	*One simple averaging	10,000) able when the averaging function is turned on. up equation uses three calculation spots. (The two calculations g the calculation number for simple averaging will be unavailable.)				
Real-time wavefor	m processing *	Option to be specified upon order (Order code: MR6000-01)				
Calculation targets	Measurement chan	nels in 8966, 8967, 8968, U8969, 8970, 8971, 8972, 8973, , U8975, U8976, U8977, U8978, U8979				
Calculation update	*The MR8990 DVM UNI 10 M, 1 M, 100 k, 1	T performs calculations only for the top 16 bits of the 24-bit AD resolution. 0 k, 1 k, 100, 10, 1 [S/s]				
rate		ns can be set for 10 MS/s. *Some types of calculations certain calculation update rates. 10 MS/s 1 MS/s 100 kS/s 10 kS/s or less				
	Calculation delay	6.2 or 6.3 us 5 us 20 us Calculation update rate period				
Calculation delay	selected for calculati					
	Added calculation delay	1.6 us 2 us 10 us Calculation update rate period				
Calculation type	equations, monomials,	nultiplication, division, four arithmetic operations with coefficients, quartic polynomial addition and subtraction, differentiation, integrals, integration, BSF), IIR (LPF / HPF / BPF / BSF), moving average, delay device				
FFT calculation *N Maximum number of calculations		FIR (LPF / HPF / BPF / BSF), IIR (LPF / HPF / BPF / BSF), moving average, delay device t available with envelope setting, not available simultaneously with real-time saving				
Frequency range	500 mHz to 100 MH	Hz (sampling rate x0.5), external sampling				
Number of sampling points Frequency resolution		00, 1/5000, 1/10,000, 1/25,000, 1/50,000				
Anti-aliasing filter		, waveform processing LPF filter (FIR, IIR), real-time ng LPF filter (FIR, IIR)				
Calculation targets	Analog waveform, wa	veform processing results, real-time waveform processing results				
Analyzed data	Newly loaded Memory	Data newly measured by pressing START key Data measured most recently or data loaded from media				
FT analysis modes	power spectrum, tra	MS spectrum*, power spectrum*, 1CH phase spectrum, cross ansfer function, coherence function, 2CH phase spectrum ortion (THD) is displayed with a cursor set to on.				
Windows	Rectangular, Hanning	g, Hamming, Blackman, Blackman-Harris, Flat-top, Exponential				
Display scale Peak value display	OFF, local maxima,	maximum value				
Averaging function	2 to 10,000 times)	exponential averaging, peak hold (arbitrary setting from				
Calculation execution button Memory division	Execution button di	ispiayed III Scieetii				
Max. divisions Block search	1024 blocks	ta that is saved in divided memory block.				
	Superimposes wav	eforms of a specific block.				
Reference block	previously measure	sently displayed on the screen can be compared with dwaveform data that is loaded in the reference block.				
Batch save Waveform search	Saves entire range	of data in all blocks last measured				
	Trigger	Level, window-in, window-out Logic trigger search is available when a logic channel is selected as the targeted channel.				
	Peak	*Logic trigger search is not available with envelope setting. Maximum value, minimum value, local maxima, local minima				
Search method	CONCIERGE	Histogram, standard deviation "Select whether to compare each value to the reference waveform or to the directly preceding waveform. "Disabled with envelope setting				
	Jump	Event mark, cursor, time (absolute time, relative time, or time specified by the number of points), trigger point, search mark				
Search range	Full range Specifying	All of the data stored in the internal memory Select either the range specified for segment 1 or the one				
Number of searches	segments Specifiable (Up to	specified for segment 2.				
Target channels Search position	Built-in unit, real-tim	ne waveform processing, waveform calculation ed to, and event marks can be set at, search positions.				
Continuous search		ecuted, if there are more search hits in the search range ed number, the waveform data following the last search				
Display method	point is continued for Specify a search lo	or searching. cation to display the data.				
CAN measurement		CAN FD, CAN (High Speed)				
	Supported	Vector Informatik VN1610, VN1630A, VN1640				
	products Connector	Compatible transceivers: CANpiggy 1051cap/1057Gcap USB				
	Number of connectable devices	1 (If multiple devices are connected, only the first detected interface will be available for use.)				
	Number of input	Up to 4 (C1 to C4) When 4 transceivers are affixed to VN1630A or VN1640				
	CAN ports	(Not available simultaneously with LIN measurement) 33.3 k, 50 k, 83.3 k, 100 k, 125 k, 250 k, 500 k,				
nterface	Baud rate	1 M [baud] 33.3 k, 50 k, 83.3 k, 100 k, 125 k, 250 k, 500 k,				
	Data rate	1 M, 2 M, 4 M [baud] *Setting available only when CAN FD is selected.				
	Acceptance filter	11-bit (standard), 29-bit (extended) Block setting is available for all frames.				
	ACK	Normal / ACK OFF CAN frame data inputted in synchronism with the start of				
	Storage memory	measurement can be stored in the build-in memory (up to 10 MB). Data is cleared every time measurement starts.				
	Monitor function	Yes Signal number: From 1				
		Signal name: up to 32 characters				
Signal settings	Definition settings	ID: 0 to 1FFFFFFF Start bit: 0 to 511 Bit length: 1 to 64 Byte order: Big / Little Data type: Signed, Unsigned, Float, Double				
	Number of signals	Conversion into physical quantity:Conversion using conversion ratio and offset				
	that can be registered	Up to 300				
	Input method	Direct entry on the instrument's display Import of a CANdb file (.DBC) or Hioki CAN definition data file (.CDF)				
	Number of displayed waveforms	Up to 64				
	waveforms Configuration	Up to 64 Select the arithmetic expression CAN/LIN in the waveform calculation setting and specify signals using signal				
Real-time waveform display Waveform display	waveforms	Up to 64 Select the arithmetic expression CAN/LIN in the waveform				

Transmit function Transmit func		1	
Types Sandard CAN, standard		Timing Transmit ID	Key S1, Key S2, Start, Trigger, Reply, Pass, Fail, Error 0 to 1FFFFFFF
Transmit function DCC		Transmit port	
Debity Do to 10000 me Personal	Tono and the section	Types	
Periodic transmit. Repeated transmission (select key St., key S22, or start) interval. Personal flower to be after require transmission: to 1000 or 16FFFFFF (il firring is set to response). LIN measurement. Conforming standard. LIN. Supported. VM16 11. NM1500A (Vector Informatic) products. Installable transceiver: LINpiggly 726/mag. Connector. USB Number of log. On One Connecticle. Interval of Installable transceiver: LINpiggly 726/mag. Connector. USB Number of log. One Connector. USB (In more than one instaface is connected, only the one connectible. Interval of Innoversity of Inno	ransmit function		
Contenting standard LIN Supported Contenting standard LIN Supported Contenting standard LIN Supported Contenting standard LIN VINES IN MISSION (Vector Informatis') Contenting standard LIN VINES IN LINES (VINES Connector LIND (VINES Contenting standard LIN VINES (VINES LIND (VINES Contenting standard LIN VINES (VINES VINES (VINES VINES VINES VINES VINES (VINES VINES VINES VINES (VINES VINES VINES VINES (VINES VINES VINES VINES VINES (VINES VINES VINES VINES (VINES VINES			
Conforming standard LIN Supported products White It NN ISSDA (Vector Information products Conforming standard LIN Supported products White It NN ISSDA (Vector Information products Connector USB USB Connector USB			Transmit interval can be set for regular transmission: 1 to 10000 ms
Supported products installable transelver. Lilhypiggy 7268mag products installable transelver. Lilhypiggy 7268mag products installable transelver. Lilhypiggy 7268mag (interface) LISB Number of Connectible (interface) Conne	LIN measurement	Response ID	to to terrere (ii timing is set to response)
products comectors USB Number of Connectors			
Interface			
interface Connectible Ciff more than one inefface is connected, only the one detected first can be used.)			
Interface Number of Input Lin ports		connectible	(If more than one interface is connected, only the one
LIN protes Characteristics Characteristics Lin protect Characteristics Lin protect Lin			Up to four (C1 to C4)
Baud rate 2400, 9600, 14400, 19200 (tps)	Interface		(Not available simultaneously with CAN / CAN FD
LIN protocol 1.3 / 2.0 / 2.1 / 2.2		Baud rate	
Storage memory measurement can be stored in the built-in memory (up to 10 MB) plate will be cleared every time measurement start Yes		LIN protocol	1.3 / 2.0 / 2.1 / 2.2
Monitor function Signal number: From 1 Signal number: From 1 Signal number: From 1 Signal number: Signa		Storage memory	measurement can be stored in the built-in memory (up to
Signal number: From 1 Signal annew: Up to 32 characters ID: 0 to 63 Start bit: 0 to 63 Start bit: 0 to 63 Start bit: 0 to 64 Bit length: 1 to 64 B		Monitor function	
Definition			Signal number: From 1
Befinition Bit length: 1 to 64 Byte order Big. Little Data type. Signed. Unsigned, Float, Double Checksure, Classic, Enhanced Conversion using conversion ratio and offset Double Checksure, Classic, Enhanced Conversion using conversion ratio and offset Double Checksure, Classic, Enhanced Conversion using conversion ratio and offset Double Checksure, Classic, Enhanced Conversion using conversion ratio and offset Double Checksure, Classic, Enhanced Conversion ratio and offset Double Checksure, Classic, Enhanced Conversion using conversion ratio and offset Double Checksure, Classic, Enhanced Checksure, Classic, Cla			ID: 0 to 63
Data type: Signed, Unsigned, Float, Double Checksum: Classie, Enhanced Conversion unto physical quantity. Conversion using conversion and offset of the conversion with physical quantity. Conversion using conversion and offset of the conversion with physical quantity. Conversion using conversion and offset of the conversion with physical quantity. Conversion using conversion and offset of the conversion with physical quantity. Conversion using conversion with physical quantity. Conversion using conversion and offset of the conversion of the conver			Bit length: 1 to 64
Conversion into physical quantity: Conversion using conversion ratio and offset Number of definition that can be registered in humber of displayed waveforms. In Junt method of displayed waveforms are also of displayed waveforms. Calculation waveform display waveforms. Calculation waveforms. Ca	Signal configuration	Comiguration	Data type: Signed, Unsigned, Float, Double
Number of definitions Up to 300			Conversion into physical quantity: Conversion using
United an Entergraphic Control		Number of definitions	
Real-time waveform displayy waveforms displayy Waveform generation Debails of the hardware functions comply with MRB790, MRB791 and U8793 units. Waveform generation Debails of the hardware functions comply with MRB790, MRB791 and U8793 units. Waveform generation mode Signal generation On (generation), off (hal) Synchronized control Synchronized generation of generation units of MRB790, MRB791 and U8793 units. Waveform generation Signal generation Waveform Generation Control Synchronized generation of generation, off (hal) Synchronized generated signals via all channels in spruch those another. Outputs generated signals via all channels in spruch those another. Outputs generated signals via all channels in spruch those another. Outputs generated signals via all channels in spruch those another. Outputs generated signals via all channels in spruch with one another. Outputs generated signals via all channels in spruch one another. Outputs generated signals via all channels in spruch one another. Outputs generated signals via all channels in spruch one another. Outputs generated signals via all channels in spruch one another. Outputs generated signals via all channels in spruch one another. Outputs generated with the start and stop of measurement. Waveforms generated with separate signals via all cannels in spruch one another. Outputs generated with Model Reposition of measurement. Supported waveforms for output (U8739 only) Waveform reasured with Model Reposition wave, rectangular wave, rect			
How to configure Select the arithmetic expression CANULIN in the waveform display Waveform generation Waveform generation Up to 16	Real-time waveform	Number of displayed	
Calculation waveform Sideplay of displayed up to 16 Waveform generation Details of the hardware functions comply with MR8790, MR8791 and U8793 units. Waveform generation mode Signal generation on (generation) on (generation), off (halt) Synchronized Synchronization of all channels with one another. Outputs generated signals via all channels in sync with one another. Outputs generated signals via all channels in sync with one another. Outputs Synchronized on the start and stop of measurement. Outputs signals in sync with the start and stop of measurement. Waveform GENERATOR UNIT MR8791 ARBITRARY WAVEFORM GENERATOR UNIT Waveform, programmed waveform vaveforms produced waveforms for supported waveforms and supported or waveforms and supported or waveforms and the supported or waveforms and supported or waveforms and supported or waveforms and supported or waveforms are supported or waveforms and supported or waveform supported or waveform and supported or waveform and supported or waveform supported or waveform data initialization, setting initialization or waveform data initialization, sett	display		
Waveform generation Totalis of the hardware functions comply with MR8790. MR8791 and U8793 units. By the respective generation on (generation). Off (helt) Signal generation Control Signal generation Control Signal generation Control Synchronization of all channels with one another. Outputs generated signals via all channels in sync with one another. Synchronization of all channels in sync with one another. WAVEFORM GENERATOR UNIT MR8790 PLLS GENERATOR UNIT ARBTRAY WAVEFORM ARBTRAY WAVEFOR	Calculation waveform display		
Details of the hardware functions compty with MR3790 MR3791 and U8793 units.	Wayoform ganarati	waveforms	Up to 16
Signal generation On (generation), off (halt) Synchronization of all channels with one another: Outputs generated control Synchronization of all channels with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated signals via all channels in sync with one another: Outputs generated with Model of Property of the start and stop of measurement. Waveform (Seneration Will 1973) Reported waveforms (Seneration Will 1973) Waveforms measured with Model MR6000/MR6000-01 Memory HiCorder (logi waveforms saved with Model SF8000 Waveform Maker Waveforms saved with Model SF8000 Waveform Maker Other "When the power is turned on, the unit loads the settings data Available previously saved (STARTUP-SET) to start up. "The HDD/SSD, SD memory card, and USB memory are searched, in that order, for the save location. In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range, compression rate, or display position can be changed and the cursor can be moved. Were of the save located. Available (The optimal sampling rate and measurement range for the input waveform are automatically) set.) "Not available for envelope, real-time saving, or external sampling. The event of the save located. Available for envelope, real-time saving, or external sampling. Sending e-mails via SMTP Sending e-mails via SMTP Sending e-mails via SMTP Sending firming Automatic saving, saving with the SAVE button Send and the cursor can be moved. Sending e-mails via SMTP Sending time	*Details of the hardware		MR8790, MR8791 and U8793 units.
Synchronized control	Waveform generation mode	By the respective g	eneration units of MR8790, MR8791 and U8793
Synchronized generated signals via all channels in sync with one another. Control Synchronization with measurement. Outputs signals in sync with the start and stop of measurement. WaveForM GENERATOR UNIT PUSE GENERATOR UNIT MR6791 PUSE GENERATOR UNIT PUSE, pattern MR6791 ARBITRARY WAVEFORM GENERATOR UNIT PUSE of the start and stop of measurement. Waveforms measured with Model ARBIGOOM/MR6000-01 Memory HiCorder (logi waveforms assed with Model ARBIGOOM/MR6000-01 Memory HiCorder (logi waveforms saved with Model SF8000 Waveform Maker Other Waveforms generated with Model SF8000 Waveform Maker Other "When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. "The HDD/SSD, 5D memory card, and USB memory are searched, in the toricolar direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available for envelope, real-time saving, or external sampling. Three levels of settings are available. OFF, touch screen only, or touch screen and hard buttons. Sending e-mails via SMTP Sending it may be a function of the sp		Signal generation	
the start and stop of measurement. WaveFORM GENERATOR DC, sine wave PULSE GENERATOR UNIT MR879 PULSE GENERATOR UNIT MR879 ARBITRARY WAVEFORM GENERATOR UNIT Juste, pattern MR879 ARBITRARY WAVEFORM GENERATOR UNIT Juste, pattern MR879 ARBITRARY WAVEFORM GENERATOR UNIT Juste, pattern MR879 ARBITRARY WAVEFORM GENERATOR UNIT Juste wave, ramp-up wave, ramp-down wave, arbitrary generated waveforms programmed waveform Waveforms measured with Model MF6000/MF6000-01 Memory HiCorder (logi waveforms of supported) Waveforms served with Model F8000 Waveform Generator Waveforms generated with Model F8000 Waveform Maker **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data previously saved (STARTUP-SET) to start up. **When the power is turned on, the unit loads the settings data **When the power is turned on, the unit loads the settings data **When the power is turned on, the unit loads the settings data **When the power is turned on, the unit loads the settings data **When the power is turned on, the unit loads the settings data **When the power is turned on, the unit loads the settings of the unit loads the settings of the unit loads the settings are available. The save the measurement range, compression rate, or display position can be changed and	Waveform generation control		generated signals via all channels in sync with one another.
Waveform types December Dece		control	
Milifary pulse, pattern ABITRAPY WAVEFORM GENERATOR UNIT UR38 pulse wave, traingular wave, rectangular wave, and ABITRAPY WAVEFORM GENERATOR UNIT UR38 pulse wave, traingular wave, rectangular wave, and the provided waveforms of supported waveforms measured with Model 17075 Waveform Generator Waveforms saved with Model 17075 Waveform Generator Waveforms generated with Model 578000 Waveform Maker Other Auto setup Available waveforms is turned on, the unit loads the settings data previously saved (STARTUP, SET) to start up. The HDD/SSD, SD memory card, and USB memory are searched, in the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. In the vertical direction, the measurement range (compression rate, or display position can be changed and the cursor can be moved. Waveform are automatically set). "Not available for envelope, real-time saving, or external sampling. The elevels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails Sending e-mails was MTP Sending iming Automatic saving, saving with the SAVE button Self-check Memory, LCD, buttons, LAN, media, touch screen Altach data specified in the main text or files specified by a type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, exagesimal time, date, data values ON / OFF Permitted / Not permitted: Etings cannot be changed during the measuring process, the unit is restarted. *Not permitted: Etings cannot be changed during the measuring process. The found of current sentings Set the date and time. ON / OFF Protects the system against unintentional power shutdowns, (However, we recommend turning off the system			DC, sine wave
ARBITRAPY WALFEORM GENERATOR UNIT UR193 GENERATOR UNIT UR193 Supported wavelorms for pulped wave, remp-up wave, rectangular wave, arbitrary waveforms provided waveforms not supported) Waveforms provided waveforms not supported) Waveforms provided waveforms not supported) Waveforms of supported) Waveforms of supported) Waveforms saved with Model MR6000/MR6000-01 Memory HiCorder (logi waveforms of supported) Waveforms saved with Model S705 Waveform Generator Waveforms saved with Model S705 Waveform Maker Other Autiliable The HDD/SSD, SD memory card, and USB memory are searched, in that order, for the save location. In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails via SMTP Sending e-mails via SMTP Sending timing Automatic saving, saving with the SAVE button Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and waming display Displays the details of errors and warnings when they occur. Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an externa	Waveform types		pulse, pattern
Supported waveforms for pulput (1979 only) Waveforms measured with Model RR6000/MR6000-01 Memory HiCorder (logi waveforms and supported) Waveforms saved with Model 7075 Waveform Generator Waveforms saved with Model 7075 Waveform Generator Waveforms generated with Model 578000 Waveform Maker Other When the power is turned on, the unit loads the settings data previously saved (STARTUP, SET) to start up. "The HDD/SSD, SD memory card, and USB memory are searched, in that order, for the save location. X	31.		DC, sine wave, triangular wave, rectangular wave,
Supported waveforms for waveforms not supported) waveforms generator waveforms generated with Model 7075 Waveform Generator Waveforms generated with Model SF8000 Waveform Maker **When the power is turned on, the unit loads the settings data previously saved (STARTUP SET) to start up. **The HDD/SSD, SD memory card, and USB memory are searched, in that order, for the save location. **Rotary knobs** **In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. **In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. **Shortcut button** **St. S2** **A function can be allocated. **Available (The optimal sampling rate and measurement range for the input waveform are automatically set.)** **Not available for envelope, real-time saving, or external sampling. **Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. **Beep sound** **OFF, alarm only, alarm and operation** **Sending e-mails** **Sending e-mails** **Sending timing Automatic saving, saving with the SAVE button** **Sending timing Automatic saving, saving with the SAVE button** **Sending timing Automatic saving, saving with the SAVE button** **Self-check Memory, LCD, buttons, LAN, media, touch screen** **English, Japanese, Chinese** **Error and waming display** **Displays the details of errors and warnings when they occur.** **Displays the details of errors and warnings when they occur.** **Settings for decimal point and break characters in data saved to waveform (text) flies and numerical calculation result flies** **Decimal point** **Perival display** **Waveform screen** **Beak** **Comma, space, tab, semicolon** **Hours, sexagesimal time, date, data values** **Orman, space, tab, semicolon** **Hours, sexagesimal time, date, data values** **Orman, space, tab, semicolon** **Hours, sexagesimal time, date, data values** **Orman, space, tab, se			waveform, programmed waveform
Auto setup **When the power is turned on, the unit loads the settings data previously saved (STARTUP.SET) to start up. *The HDD/SSD, SD memory card, and USB memory are searched, is that order, for the save location. **Rotary knobs** **Rotary knobs** **Rotary knobs** **Rotary knobs** **Rotary knobs** **In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. **In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. **Available (The optimal sampling rate and measurement range for the input waveform are automatically set.)** **Not available for envelope, real-time saving, or external sampling. **Key lock** **Beep sound** **OFF, alarm only, alarm and operation** **Sending e-mails via SMTP** **Sending e-mails via SMTP** **Sending e-mails via SMTP** **Sending e-mails via SMTP** **Sending timing** **Autach data specified in the main text or files specified by a type of saved data. **Initialization** **When the power is turned on, the unit loads the settings for decimal point and break characters in data saved to waveform (type) the check betails of errors and warnings when they occur. **Touch keyboard** **Region specifications** **Region specifications** **Region specifications** **Region specifications** **Region specifications** **Region display** **Permitted / Not permitted: If settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted or the PROBE PO	Supported waveforms for	waveforms not supp	ported)
Auto setup When the power is turned on, the unit loads the settings data previously saved (STARTUP.SET) to start up. The HDD/SSD, SD memory card, and USB memory are searched, it that order, for the save location. X In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. Y In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Auto range Auto range Auto range Autotion S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails Sending e-mails via SMTP Sending iming Automatic saving, saving with the SAVE button Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and waming display Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Poreletcts the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections.			
Available previously saved (STARTUP.SET) to start up. "The PLDD/SSD, SD bemony card, and USB memory are searched, is that order, for the save location." X In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. Y In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Sending e-mails via SMTP Sending e-mails via SMTP Sending imming Automatic saving, saving with the SAVE button Sent data Attach data specified in the main text or files specified by a type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values Displays ettings ON / OFF Protects the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CUPRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections.	Other	*When the	e power is turned on, the unit loads the settings data
that order, for the sawe location. X In the horizontal direction, the sampling rate, compression rate, or display position can be changed and the cursor can be moved. Y In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Autiliable (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails via SMTP Sending fe-mails via SMTP Sending fe-mails via SMTP Sending timing Automatic saving, saving with the SAVE button Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and waming display Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values Displays ettings Permitted / Not permitted: If settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted." Not permitted: Settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings are changed during the measuring process, thurit is restarted." Not permitted: Settings cannot be changed during the measuring process. In unit is restarted. "Not permitted: Settings are changed during the measuring process, thurit is restarted." Not permitted: Settings cannot be changed during the measuring process. The variety of the system protection function and mounting an external UPS when using the unit continuously for long perio	Auto setup	Avoilable previously	y saved (STARTUP.SET) to start up.
Adulable (The optimals sampling rate and measurement range, compression rate, or display position can be changed and the cursor can be moved. Y In the vertical direction, the measurement range, compression rate, or display position can be changed and the cursor can be moved. Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails Sending e-mails via SMTP Sending e-mails via SMTP Sending iming Automatic saving, saving with the SAVE button Sent data Attach data specified in the main text or files specified by a type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Black or white Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted." Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted settings cannot be changed during the measuring process, the unit is restarted." Not permitted settings cannot be changed during the measuring process, the unit is restarted. "Not permitted settings cannot be changed during the measuring process. The proc		that order	r, for the save location.
Shortcut button S1, S2 A function can be allocated. Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails Sending e-mails	Rotary knobs	^ display p	osition can be changed and the cursor can be moved.
Auto range Available (The optimal sampling rate and measurement range for the input waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails via SMTP Sending e-mails via SMTP Sending e-mails via SMTP Sending imping Automatic saving, saving with the SAVE button Self-check data specified in the main text or files specified by a type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Displays settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT 8977: Up to 4 slots		or display	position can be changed and the cursor can be moved.
Auto range waveform are automatically set.) Not available for envelope, real-time saving, or external sampling. Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails Sending e-mails via SMTP Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Sending e-mails Automatic saving, saving with the SAVE button Automatic saving	Shortcut button		
Three levels of settings are available: OFF, touch screen only, or touch screen and hard buttons. Beep sound OFF, alarm only, alarm and operation Sending e-mails via SMTP Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending timing Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Sending e-mails and Automatic saving, saving with the SAVE button Self-check Automatic saving, saving with the SAVE button Memory, LCD, buttons, LAN, media, touch screen English, Japanese, Chinese Error and waming display Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) flies and numerical calculation result flies Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measur	Auto range	waveform are autor	natically set.)
Beep sound OFF, alarm only, alarm and operation Sending e-mails via SMTP Sending e-mails via SMTP Sending e-mails via SMTP Sending e-mails via SMTP Sending timing Automatic saving, saving with the SAVE button Attach data specified in the main text or files specified by a type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Time value display Waveform screen background color Restart permission Displays settings Permitted / Not permitted: If settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process." System protection For protection display Unit Bey71, and 3ch CURRENT UNIT U8977 "When using the CT6711, up to 4 connections. Unit installation Unit installation Unit installation Unit installation Unit installation OVERENT UNIT 8971: up to 4 slots	Kev lock	Three levels of settir	
Sending e-mails via SMTP Sending e-mails Automatic saving, saving with the SAVE button Sent data Attach data specified in the main text or files specified by a type of saved data. Material Self-check Memory, LCD, buttons, LAN, media, touch screen Language English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Time value display All Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Displays settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections. Unit installation CURRENT UNIT 8971: Up to 4 slots	Beep sound		arm and operation
Sent data Attach data specified in the main text or files specified by a type of saved data. Mayeform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Time value display Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Display settings Aditach data specified in the main text or files specified by atype of saved data. Attach data specified in the main text or files a type of saved data. Attach data specified in the main text or files appeal of save by setting settings. Altach data specified in the main text or files by setting settings when they occur. Touch screen background color Break Comma, space, tab, semicolon Black or white Black or white Permitted / Not permitted 'Permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted Seltings cannot be changed during the measuring process, the unit is restarted. "Not permitted Seltings cannot be changed during the measuring process." ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots		Sending e-mails via	a SMTP
A type of saved data. Initialization Waveform data initialization, setting initialization, complete initialization Self-check Memory, LCD, buttons, LAN, media, touch screen English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Black or white Permitted / Not permitted: If settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process, thurit is restarted." Not permitted: Settings cannot be changed during the measuring process. The date and time. ON / OFF Protects the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT 18977 "When using the CT67110, up to 4 connections. Unit installation CURRENT UNIT 8971: Up to 4 slots	Sending e-mails		Attach data specified in the main text or files specified by
Self-check Memory, LCD, buttons, LAN, media, touch screen English, Japanese, Chinese Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) flies and numerical calculation result flies Decimal point Period, comma Break Comma, space, tab, semicolon Time value display Hours, sexagesimal time, date, data values ON / OFF Waveform screen Black or white Designating of the visit of the sex of	Initialization		
Error and warning display Displays the details of errors and warnings when they occur. Touch keyboard Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Display settings Permitted / Not permitted: If settings are changed during the measuring process, thurit is restarted. "Not permitted: Settings cannot be changed during the measuring process." System protection function Number of current sensor connections Unit installation Displays the details of errors and warnings when they occur. Set the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections.	Self-check	Memory, LCD, butto	ons, LAN, media, touch screen
Displays the on-screen keyboard. Settings for decimal point and break characters in data saved to waveform (text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Black or white Black or white Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. Not permitted: Settings cannot be changed during the measuring process. Display settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF System protection function Number of current sensor connections Unit installation CURRENT UNIT 8971. and 3ch CURRENT UNIT 18977 "When using the CT6711 or CT6711, up to 4 connections.	Language Error and warning display		
(text) files and numerical calculation result files Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Waveform screen background color Restart permission Display settings Permitted / Not permitted 'Permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted Settings cannot be changed during the measuring process." Permitted / Not permitted settings are changed during the measuring process, the unit is restarted. "Not permitted settings are changed during the measuring process." Permitted / Not permitted settings are changed during the measuring process, the unit is restarted. "Not permitted settings are changed during the measuring process." Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process, the process are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process, the process are changed during the measuring process. Permitted / Not permitted if settings are changed during the measuring process. Permitted / Not permitted if settings	Touch keyboard	Displays the on-scr	een keyboard.
Decimal point Period, comma Break Comma, space, tab, semicolon Hours, sexagesimal time, date, data values ON / OFF Black or white Black or white Black or white Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. Not permitted: Settings cannot be changed during the measuring process. Display settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF System protection function external UPS when using the unit continuously for long periods of time.) Up to 9 connections altogether on the PROBE POWER UNIT Z5021, CURRENT UNIT 8971, and 3ch CURRENT UNIT UR977 "When using the CT6711 or CT6711, up to 4 connections.		Settings for decima (text) files and num	I point and break characters in data saved to waveform erical calculation result files
Time value display Hours, sexagesimal time, date, data values ON / OFF Black or white Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process. The settings are changed during t	Region specifications	Decimal point	Period, comma
Zero position display ON / OFF Black or white Black or white Permitted / Not permitted: If settings are changed during the measuring process, the unit is restarted. "Not permitted: Settings cannot be changed during the measuring process, the unit is restarted." Not permitted: Settings cannot be changed during the measuring process. Display settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) Number of current sensor connections Unit 18971, and 3ch CURRENT UNIT 18977 "When using the CT6710 or CT6711, up to 4 connections.	Time value display		
Background color Flemitted / Not permitted: If settings are changed during the measuring process, thurits restarted. Not permitted: Settings cannot be changed during the measuring process. Display settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF System protection function and mounting an external UPS when using the unit continuously for long periods of time. Up to 9 connections altogether on the PROBE POWER UNIT Z5021, CURRENT UNIT 18971, and 3ch CURRENT UNIT 18977 "When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots	Zero position display		
unit is restarted. "Not permitted: Settings cannot be changed during the measuring process. Display settings Adjust brightness or set the display to turn off automatically. Set the date and time. ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) Number of current sensor connections Up to 9 connections altogether on the PROBE POWER UNIT Z5021, CURREN UNIT 8971, and 3ch CURRENT UNIT UR977 "When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots	Waveform screen background color		
Time settings Set the date and time. ON / OFF System protection function Number of current sensor connections Unit installation Set the date and time. ON / OFF System against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) UNIT 8971, and 3ch CURRENT UNIT U8977 When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots	Restart permission		
ON / OFF Protects the system against unintentional power shutdowns. (However, we recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) Number of current sensor connections UNIT 8971, and 3ch CURRENT UNIT US977 When using the CT6710 or CT6711, up to 4 connections. Unit installation URRENT UNIT 8971: Up to 4 slots	Display settings	Adjust brightness o	r set the display to turn off automatically.
recommend turning off the system protection function and mounting an external UPS when using the unit continuously for long periods of time.) Up to 9 connections altogether on the PROBE POWER UNIT Z5021, CURREN UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots		ON / OFF	
Number of current sensor connections altogether on the PROBE POWER UNIT Z5021, CURREN' UNIT 8971, and 3ch CURRENT UNIT U8977 "When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots	System protection function	recommend turning	off the system protection function and mounting an
UNIT 8971, and 3ch CURRENT UNIT U8977 When using the CT6710 or CT6711, up to 4 connections. CURRENT UNIT 8971: Up to 4 slots	Number of august	1	
Unit installation CURRENT UNIT 8971: Up to 4 slots	Number of current sensor connections	UNIT 8971, and 3cl	h CURRENT UNIT U8977
	Unit installation	CURRENT UNIT 89	71: Up to 4 slots

Option Specifications (sold separately)

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 280 g (9.9 oz.), Accessories: None



196.5 min (7.74 m.) D, approx. 260 g (9.9 dz.), Accessories. None			
HIGH SPEED ANAL U8976	OG UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement		
Input terminals	Isolated BNC connector (input impedance 1 M Ω , input capacitance 22 pF) Max. rated voltage to ground:1000 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass liter: 5/500/5 k/1 MHz		
Measurement resolution	1/1600 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	200 MS/s (simultaneous sampling in 2 channels)		
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)		
Frequency characteristics	DC to 30 MHz -3 dB (with AC coupling: 7 Hz to 30 MHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (with direct input), 1000 V DC (with 9665)		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None			
ANALOG UNIT 896	6	(Accuracy at 23 $\pm 5^{\circ}$ C/73 $\pm 9^{\circ}$ F, 20 to 80% RH af up time and zero adjustment; Accuracy guarante	
Measurement functions	No. of channels: 2	, for voltage measurement	
Input terminals	Max. rated voltage maximum voltage	nector (input impedance 1 MΩ, input capace to ground: 300 V AC, DC (with input isolat that can be applied between input channe innels without damage)	ted from the unit, the
Measurement range	AC voltage for pos	f.s. 100, 200, 400 V f.s., 12 ranges ssible measurement/display: 280 V rms 50/500/5 k/50 k/500 kHz	
Measurement resolution	1/2000 of measure	ement range (using 12-bit A/D conversion)	
Maximum sampling rate	20 MS/s (simultane	eous sampling across 2 channels)	
Measurement accuracy	±0.5% f.s. (with filt	er 5 Hz, zero position accuracy included)	
Frequency characteristics	DC to 5 MHz -3 dE	3 (with AC coupling: 7 Hz to 5 MHz -3 dB)	
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maxis	mum voltage that can be applied across input	pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D. approx. 250 g (8.8 oz.). Accessories: None



196.5 mm (7.74 in.) D, ap	orox. 250 g (8.8 oz	i.), Accessories: None	
4CH ANALOG UNI	T U8975	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% warm-up time and zero adjustment; Accur	
Measurement functions	No. of channels: 4,	for voltage measurement	
Input terminals	Max. rated voltage maximum voltage t	ector (input impedance 1 MΩ, input ca to ground: 300 V AC, DC (with input is hat can be applied between input char nnels without damage)	olated from the unit, the
Measurement range	4, 10, 20, 40, 100, 2 AC voltage for poss Low-pass filter: 5/5	sible measurement/display: 140 V rms	
Measurement resolution	1/32,000 of measur	rement range (using 16-bit A/D convers	sion)
Maximum sampling rate	5 MS/s (simultaneo	us sampling in 4 channels)	
Measurement accuracy	±0.1% f.s. (with filte	r 5 Hz, zero position accuracy included	d)
Frequency characteristics	DC to 2 MHz -3 dB		
Input coupling	DC / GND		
Maximum input voltage	200 V DC (the maxim	num voltage that can be applied across in	put pins without damage)

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



130.3 Hill (1.14 III.) B, approx. 230 g (0.0 02.), Accessories. Notice			
4CH ANALOG UNI	T U8978	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% F warm-up time and zero adjustment; Accura	
Measurement functions	No. of channels: 4,	for voltage measurement	
Input terminals	Max. rated voltage (CAT II) when com	ector (input impedance 1 $M\Omega$, input cap to ground: 30 V AC or 60V DC for dire- bined with the 9665 (Between each veen the input channels)	ct input, 300 V AC, DC
Measurement range	100, 200, 400 mV fs. 1, 2, 4, 10, 20, 40 V fs., 9 ranges Low-pass filter: 5/500/5 k/200 kHz		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	5 MS/s (simultaneous sampling in 4 channels)		
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)		
Frequency characteristics	DC to 2 MHz -3 dB		
Input coupling	DC/GND		
Maximum input voltage	40 V DC (with direct input), 400 V DC (with 9665)		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 260 g (9.2 oz.), Accessories: None



130.5 Hill (7.74 iii.) D, approx. 200 g (3.2 02.), Accessories. Notice			
DIGITAL VOLTMET MR8990			20 to 80% RH after 30 minutes of ccuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2,	for DC voltage measureme	ent
Input terminals	Banana input connectors (Input resistance: $100~M\Omega$ or higher with $100~mV$ f.s. to $10~V$ f.s. range, otherwise $10~M\Omega$) Max. rated voltage to ground: $300~V$ AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 1000 mV f.s. 10, 100, 1000 V f.s., 5 ranges		
Measurement resolution	1/1,000,000 of measurement range (using 24-bit ΔΣ modulation A/D)		
Integration Time	20 ms × NPLC (during 50 Hz), 16.67 ms × NPLC (during 60 Hz)		
Response time	2 ms +2× integration time or less (rise - f.s. → + f.s., fall + f.s. → - f.s.)		
Basic measurement accuracy	±0.01% rdg. ±0.0025% f.s. (at range of 1000 mV f.s.)		
Maximum input voltage	500 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



HIGH RESOLUTIO 8968	N UNIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)	
Measurement functions	No. of channels: 2, for voltage measurement	
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)	
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/50 kHz	
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)	
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)	
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)	
Measurement accuracy	±0.3% f.s. (with filter 5 Hz, zero position accuracy included)	
Frequency characteristics	DC to 100 kHz -3 dB (with AC coupling: 7 Hz to 100 kHz -3 dB)	
Input coupling	AC/DC/GND	
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)	

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



осто тит (т.т. т.т.) 2, арргом. 200 g (сто с2.), гособсотост топо			
DC/RMS UNIT 897	2 (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable		
Input terminals	Isolated BNC connector (input impedance 1 $M\Omega$, input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Measurement range	100, 200, 400 mV f.s. 1, 2, 4, 10, 20, 40, 100, 200, 400 V f.s., 12 ranges AC voltage for possible measurement/display: 280 V rms Low-pass filter: 5/50/500/5 k/100 kHz		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)		
Measurement accuracy	±0.5% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz) ±3% f.s. (1 kHz to 100 kHz) Response time: SLOW 5 s (rise time from 0 to 90% of full scale), MID 800 ms (rise time from 0 to 90% of full scale), FAST 100 ms (rise time from 0 to 90% of full scale) (rest factor: 2		
Frequency characteristics	DC to 400 kHz -3 dB (with AC coupling: 7 Hz to 400 kHz -3 dB)		
Input coupling	AC/DC/GND		
Maximum input voltage	400 V DC (the maximum voltage that can be applied across input pins without damage)		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 230 g (8.1 oz.), Accessories: None



HIGH-VOLTAGE UI U8974	NIT (Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage measurement, DC/RMS selectable		
Input terminals	Banana input terminal (Input impedance: $4 \text{ M}\Omega$, Input capacitance: 5 pF) Max. rated voltage to ground: 1000 V AC , DC for measurement category IV, AC, DC for measurement category IV (Between each input channel and the main unit, and between the input channels)		
Measurement range	4, 10, 20, 40, 100, 200, 400, 1000 V f.s. (DC mode), 8 ranges 10, 20, 40, 100, 200, 400, 1000 V f.s. (RMS mode), 7 ranges Low-pass filter: 5/50/500/5 k/50 kHz		
Measurement resolution	1/32,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	1 MS/s		
Measurement accuracy	±0.25% f.s. (with filter 5 Hz, zero position accuracy included)		
RMS measurement	RMS accuracy: ±1.5% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 100 kHz) Response time: High speed 150 ms, medium speed 500 ms, low speed 2.5 s		
Frequency characteristics	DC to 100 kHz -3 dB		
Input coupling	DC / GND		
Maximum input voltage	1000 V DC, 700 V AC		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 245 g (8.6 oz.), Accessories: CONVERSION CABLE L9769 x 2 (cable length 60 cm (1.97 ft.))



STRAIN UNIT U89	(Accuracy at 23 ±5°C/73 ±9°F, 80% RH or less after 30 minutes of warm-up time and auto-balance; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for distortion measurement (electronic auto-balancing, balance adjustment range within ±10,000 με or less)		
Input terminals	NDIS connector EPRC07-R9FNDIS (via CONVERSION CABLE L9769, NDIS connector PRC03-12A10-7M10.5) Max. rated voltage to ground: 30 V AC rms or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage)		
Suitable transducer	Strain gauge converter, Bridge impedance: 120 Ω to 1 k Ω , Bridge voltage: 2 V ±0.05 V, Gauce rate: 2.0		
Measurement range	400, 1000, 2000, 4000, 10,000, 20,000 με f.s., 6 ranges Low-pass filter: 5/10/100/1 kHz		
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	200 kS/s (simultaneous sampling across 2 channels)		
Measurement accuracy After auto-balancing	1 ±0.5% f.s. ±4 με (5 Hz filter ON)		
Frequency characteristics	DC to 20 kHz +1/-3 dB		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 190 g (6.7 oz.), Accessories: None



LOGIC UNIT 8973	
Measurement functions	No. of channels: 16 channels (4 ch/1 probe connector × 4 connectors)
	Mini DIN connector (for HIOKI logic probes only), Compatible logic probes: 9320-01, 9327, MR9321-01



3CH CURRENT UNIT U8977 Measurement functions No. of channels: 3, Current measurement with optional current sensor Dedicated connector terminal (ME15W) (input impedance 1 MΩ, common Input terminals GND with recorder) 9272-05, CT6841-05, CT6843-05, CT6844-05, CT6845-05, CT6846-05, CT6862-05, CT6863-05, 9709-05, CT6904, CT6865-05, CT6875, CT6876, Compatible current CT6877 (Direct connection)
CT7631, CT7636, CT7642, CT7731, CT7736, CT7742, CT7044, CT7045, CT7046 (Connection using optional CONVERSION CABLE CT9920)
- Directly connected current sensor: Automatically identify rating of sensors compatible current sensors
Using 9272-05 (20 A), CT6841A:
2 A/ 4 A/ 10 A/ 20 A/ 40 A/ 100 A f.s.
Using CT6862-05, CT6872: Osing C10022-0, V10072-4 A/ 10 A/20 A/40 A/ 100 A/200 A f.s. Using 9272-05 (200 A), CT6843A, CT6863-05, CT6873: 20 A/40 A/100 A/200 A/400 A/1000 A f.s. Using CT6844A, CT6845A, CT6904A, CT6875A: 40 A/100 A/200 A/400 A/1000 A/2000 A f.s. Measurement range Using CT6846A, CT6876A: 100 A/ 200 A/ 400 A/ 1000 A/ 2000 A/ 4000 A f.s. Using CT6877A: 200 A/400 A/1000 A/2000 A/4000 A/10000 A f.s. Current sensors connected using CT9920: Select conversion rate or model Using CT7631, CT7731: 200 A Using CT7636, CT7736: 200 A/ 400 A/ 1000 A Using CT7642, CT7742: 2000 A/ 4000 A Using CT7044, CT7045, CT7046: 2000 A/ 4000 A/ 10000 A *The measurable range is limited by the connected sensor(s). Please check your current sensors' specifications Measurement accuracy (with 5 Hz filter ON) ±0.3% f.s. Frequency characteristics: DC to 2 MHz ±3 dB Note: Add the accuracy and attributes of the current sensor being used. Measurement resolution 1/32,000 of measurement range (using 16-bit A/D conversion) Maximum sampling rate 5 MS/s (simultaneous sampling in 3 channels) Input coupling: DC/GND, Low-pass filter: 5/500/5 k/200 kHz

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 230 g (8.1 oz.), Accessories: None



CHARGE UNIT U897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm- up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for acceleration measurement		
Input terminals	Voltage input / pre-amp embedded input: Metal BNC connector (Under voltage input: input impedance 1 M Ω , input capacitance 200 pF or less) Charge input: Miniature connector (#10-32UNF) Max. rated voltage to ground: 30 V AC or 60 V DC (with input isolated from the main unit, the maximum voltage that can be applied between input channel and chassis, and between input channels without damage) *Voltage input terminal GND and charge input terminal GND for the same channel are shared.		
Suitable transducer	Charge output type acceleration detector Pre-amp embedded acceleration detector (IEPE type)		
Measurement range Charge input (Miniature connector) Pre-amp embedded input (BNC connector)	1 (m/s²) to 200 k (m/s²) f.s., 12 ranges x 6 types Charge input sensitivity: 0.1 to 10 pC /(m/s²) Pre-amp embedded sensor input sensitivity: 0.1 to 10 mV /(m/s²) Amplitude accuracy: ±2% f.s. Frequency characteristics: 1(1.5) to 50 kHz -3 dB (charge input) Low-pass filter: 500/5 kHz Pre-amp supply power: 3.5 mA ±20%. 22 V ±5% Maximum input charge: ±500 pC (6 ranges on high sensitivity side), 50.000 pC (6 ranges on low sensitivity side)		
Measurement range Voltage input (BNC connector)	10 mV to 40 V f.s., 12 ranges, DC amplitude accuracy: ±0.5% f.s. Frequency characteristics: DC to 50 kHz -3 dB (with DC coupling), 1 Hz to 50 kHz -3 dB (with AC coupling) Low-pass filter: 5/500/5 kHz, input coupling: AC/DC/GND Maximum input voltage: 40 V DC		
Measurement resolution	1/25,000 of measurement range (using 16-bit A/D conversion)		
Maximum sampling rate	200 kS/s		
Anti-aliasing filter	Integrated filter for suppressing aliasing distortion caused by FFT processing (automatic cutoff frequency setting/OFF)		
TEDS IEEE 1451.4 class 1 support (Support for sensor information rear automatic sensitivity setting)			

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



FREQ UNIT 8970	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80 % HH after 30 minutes of warm-up time; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, for voltage input based frequency measurement, rotation, power frequency, integration, pulse duty ratio, pulse width		
Input terminals	Isolated BNC connector (input impedance 1 M Ω , input capacitance 30 pF), Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)		
Frequency mode	Measurement range: Between DC to 100 kHz (minimum pulse width 2 μs), 20 Hz to 100 kHz f.s., 8 ranges Accuracy: ±0.1% f.s. (exclude 100 kHz range), ±0.7% f.s. (100 kHz range)		
Rotation mode	Measurement range: Between 0 to 2 million rotations/minute (minimum pulse width 2 µs), 2 kr/min to 2 Mr/min f.s, 7 ranges Accuracy: ±0.1% f.s. (exclude 2 Mr/min range), ±0.7% f.s. (2 Mr/min range)		
Power frequency mode	Measurement range: 50 Hz (40 to 60 Hz), 60 Hz (50 to 70 Hz), 400 Hz (390 to 410 Hz), 3 ranges Accuracy: ±0.03 Hz (50, 60 Hz), ±0.1 Hz (400 Hz range)		
Integration mode	Measurement range: 40 k-counts f.s. to 20 M-counts f.s. 6 ranges Accuracy: ±0.0025% f.s.		
Duty ratio mode	Measurement range: Between 10 Hz to 100 kHz (minimum pulse width 2 μs), 100% f.s. Accuracy: ±1% (10 to 10 kHz), ±4% (10 k to 100 kHz)		
Pulse width mode	Measurement range: Between 2 µs to 2 s, 10 ms to 2 s f.s. Accuracy: ±0.1% f.s.		
Measurement resolution	0.0025% f.s. (Integration mode), 0.01% f.s. (exclude integration, power frequency mode), 0.01 Hz (power frequency mode)		
Input voltage range and threshold level	±10 V to ±400 V, 6 ranges, selectable threshold level at each range		
Other functions	Slope, Level, Hold, Smoothing, Low-pass filter, Switchable DC/AC input coupling. Frequency dividing, Integration over-range keep/return		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: CONVERSION CABLE 9318 \times 2 (To connect the current sensor to the 8971)



CURRENT UNIT 897	(Accuracy at 23 ±5°C/73 ±9°F, 20 to 80% RH after 30 minutes of warm- up time and zero adjustment; Accuracy guaranteed for 1 year)		
Measurement functions	No. of channels: 2, Current measurement with optional current sensor		
Input terminals	Sensor connector (input impedance 1 MΩ, exclusive connector for current sensor via conversion cable the 9318, common GND with recorder)		
Compatible current sensors	CT6862, CT6863, 9709, CT6865, CT6841, CT6843, CT6844, CT6845, CT6846, 9272-10 (To connect to the 8971 via the CONVERSION CABLE 9318)		
Measurement range	Using 9272-10 (20 A), CT6841A: 2 A/ 4 A/ 10 A/ 20 A/ 40 A/ 100 A f.s. Using CT6862-05, CT6872: 4 A/ 10 A/ 20 A/ 40 A/ 100 A/ 200 A f.s. Using 9272-05 (200 A), CT6843A, CT6863-05, CT6873: 20 A/ 40 A/ 100 A/ 200 A/ 400 A/ 1000 A f.s. Using CT6844A, CT6845A, CT6846A, CT6875A, CT6876A: 40 A/100 A/200 A/400 A/1000 A/2000 A f.s. How to connect to 8971: use Conversion Cable 9318 + Conversion Cable CT9901 *The measurable range is limited by the connected sensor(s). Please check your current sensor's specifications.		
Measurement accuracy (with 5 Hz filter ON)	±0.65% f.s. RMS accuracy: ±1% f.s. (DC, 30 Hz to 1 kHz), ±3% f.s. (1 kHz to 10 kHz)		
Note: Add the accuracy and attributes of the current sensor being used.	RMS response time: 100 ms (rise time from 0 to 90% of full scale) Crest factor: 2 Frequency characteristics: DC to 100 kHz ±3 dB (with AC coupling: 7 Hz to 100 kHz)		
Measurement resolution	1/2000 of measurement range (using 12-bit A/D conversion)		
Maximum sampling rate	1 MS/s (simultaneous sampling across 2 channels)		
Other functions	Input coupling: AC/DC/GND, Low-pass filter: 5/50/500/5 k/50 kHz		

Dimensions/mass: approx. 106 mm (4.17 in.) W x 19.8 mm (0.78 in.) H x 204.5 mm (8.05 in.) D, approx. 240 g (8.5 oz.), Accessories: Ferrite clamp x 2



TEMP UNIT 8967	(Accuracy at 23 \pm 5°C/73 \pm 9°F, 20 to 80% RH after 30 minutes of warm-up time and zero adjustment, Accuracy guaranteed for 1 year)
Measurement functions	No. of channels: 2, for temperature measurement with thermocouple (voltage measurement not available)
Input terminals	Thermocouple input: Push-button terminal block, Recommended wire diameter: single-wire 0.14 to 1.5 mm², braided wire 0.14 to 1.0 mm² (conductor wire diameter Φ 0.18 mm (0.01 in) or more), AWG 26 to 16 Input impedance: min. 5 M Ω (with line fault detection ON/OFF) Max. rated voltage to ground: 300 V AC, DC (with input isolated from the unit, the maximum voltage that can be applied between input channel and chassis and between input channels without damage)
Temperature measurement range Note: Upper and lower limit values depend on the thermocouple	200°C (392°F) f.s. (-100°C to 200°C (-148°F to 392°F)), 1000°C (1832°F) f.s. (-200°C to 1000°C (-328°F to 1832°F)), 2000°C (3632°F) f.s. (-200°C to 2000°C (-328°F to 3632°F)), 3 ranges [Measurement resolution: 1/20,000 of measurement range (using 16-bit A/D conversion
Thermocouple range (JIS C 1602-1995) (ASTM E-988-96)	K: -200°C to 1350°C (-328°F to 2462°F), J: -200°C to 1100°C (-328°F to 2012°F), E: -200°C to 800°C (-328°F to 1472°F), T: -200°C to 400°C (-328°F to 752°F), N: -200°C to 1300°C (-328°F to 2372°F), R: 0°C to 1700°C (32°F to 3092°F), S: 0°C to 1700°C (32°F to 3092°F), B: 400°C to 1800°C (752°F to 3632°F), WR85-26): 0 to 2000°C (32°F to 3632°F) Reference junction compensation: internal/ external (switchable), line fault detection ON/OFF possible
Data refresh rate	3 methods, Fast:1.2 ms (digital filter OFF), Normal:100 ms (digital filter 50/60 Hz), Slow: 500 ms (digital filter 10 Hz)
Measurement accuracy	Thermocouple K, J, E, T, N: $\pm 0.1\%$ f.s. $\pm 1^{\circ}$ C ($\pm 1.8^{\circ}$ F), ($\pm 0.1\%$ f.s. $\pm 2^{\circ}$ C ($\pm 3.6^{\circ}$ F) at -200° C to 0° C (-328° F to 32° F). Thermocouple R, S, B, W: $\pm 0.1\%$ f.s. $\pm 3.5^{\circ}$ C ($\pm 6.3^{\circ}$ F)(at 0° C (32° F) to less than 400° C (752° F); However, no accuracy guarantee at less than 400° C (752° F) for B), $\pm 0.1\%$ f.s. $\pm 3^{\circ}$ C ($\pm 5.4^{\circ}$ F) (at 400° C or more) Reference junction compensation [RJC] accuracy: $\pm 1.5^{\circ}$ C ($\pm 2.7^{\circ}$ F) (added to measurement accuracy with internal reference junction compensation)

Dimensions and mass: approx. 106 mm (4.17 in.) W \times 19.8 mm (0.78 in.) H \times 196.5 mm (7.74 in.) D, approx. 250 g (8.8 oz.), Accessories: None



ARBITRARY WAVER	Pov	curacy at 23 ±5°C/73 ±9°F, 80% rh or less after 30 minutes or more of warm-up time; ver supply frequency range of installed MEMORY HiCORDER at 50 Hz/60 Hz ±2 Hz; suracy guaranteed for 1 year)
Output terminal	Number of channels: 2, SMB terminal (Output impedance: 1 Ω or less) Max. rated voltage to ground: 33 V rms AC or 70 V DC	
Output voltage range	-10 V to 15 V (Amplitude setting range: 0 V to 20 V p-p, Setting resolution: 1 mV)	
Max. output current	10 mA (Allowable load resistance: 1.5 kΩ or more)	
FG function	DC, Sine wave, Square wave, Pulse wave, Triangular wave, Ramp wave, Output frequency: 10 mHz to 100 kHz	
Arbitrary waveform generator mode	Waveforms measured by MR8847A, etc., generated by Hioki Model 7075 or SF8000, CSV waveforms D/A refresh rate: 2 MHz (using 16-bit D/A)	
Sweep function	Frequency, Amplitude, Offset, Duty (Pulse only)	
Program function	Max. 128 steps (Number of loops for each step, Number of total loops)	
Other	Self-test function (Voltage), External input/output control	

Dimensions and weight: approx. 106 mm (4.17 in.) W \times 19.8 mm (0.78 in.) H \times 196.5 mm (7.74 in.) D, approx. 230 g (8.1 oz.), Accessories: none



WAVEFORM GENE	RATOR UNIT MR8790 (Accuracy at 23 ±5°C [73 ±9°F], 80% rh after 30 minutes of warm-up time; accuracy guaranteed for 1 year)						
Output terminal	Number of channels: 4, SMB terminal (output impedance: 1 Ω or less)						
	Max. rated voltage to ground: 30 V rms AC or 60 V DC						
Output voltage range	 -10 V to 10 V (amplitude setting range: 0 V to 20 V p-p, setting resolution: 1 mV) 						
Max. output current	5 mA						
Output function	DC, sine wave (output frequency range: 1 Hz to 20 kHz)						
	Amplitude accuracy: ±0.25% of setting ±2 mV p-p (1 Hz to 10 kHz)						
Accuracy	Offset accuracy: ±3 mV						
	DC output accuracy: ±0.6 mV						
Other	Self-test function (voltage, current)						


Dimensions and weight: approx. 106 mm (4.17 in.) W \times 19.8 mm (0.78 in.) H \times 196.5 mm (7.74 in.) D, approx. 230 g (8.1 oz.), Accessories: none



OR UNIT MR8791	(Accuracy at 23 $\pm 5^{\circ}$ C [73 $\pm 9^{\circ}$ F], 80% rh or less with no condensation; accuracy guaranteed for 1 year)				
Number of channels: 8, Conne	ctor: D-sub, half-pitch, 50-pin				
Max. rated voltage to ground: 30	V rms AC or 60 V DC (between unit and output channels)				
Logic output, open collector or	utput				
Pattern output: read frequence	y: 10 Hz to 120 kHz, 2,048 logic patterns				
Pulse output: frequency 0.1 F	Hz to 20 kHz, duty 0.1% to 99.9%				
Logic output voltage level: 0	V to 5 V				
(high level: 3.8 V or more, low level: 0.8 V or less)					
Open collector output: 50 V absolute maximum rated voltage for collector/emitter					
Overcurrent protection: 100 mA					
Self-test function					
	Max. rated voltage to ground: 30 Logic output, open collector or Pattern output: read frequenc Pulse output: frequency 0.1 F Logic output voltage level: 0' (high level: 3.8 V or more, low Open collector output: 50 V Overcurrent protection: 100 m				

System Chart of Options

All prices are exclusive of tax



Factory-installed option A *Must specify when ordering

*Power can be supplied to up to 9 current sensors, including the current sensors connected to the CURRENT UNIT US977 and CURRENT UNIT 8971.



PROBE POWER UNIT Z5021 Specified upon order, ±12 V DC, supply for up to 8 probes

Factory-installed option B

*Must specify when ordering



SSD UNIT U8332 Specified upon order; built-in type, 256 GB

Factory-installed option C



HD UNIT U8333 Specified upon order; built-in type, 320 GB

Storage media

*Use only the storage media sold by HIOKI. Compatibility and performance are not guaranteed for storage media made by other manufacturers. You may be unable to read from or save data to such media.



SD MEMORY CARD Z4001

2 GB

SD MEMORY CARD Z4003

8 GB

USB DRIVE Z4006

16 GB Using highly durable and reliable SLC flash memory

Non-contact CAN measurement



Non-Contact CAN Sensor SP7001-90 CAN FD/CAN support, bundle including SP7001/SP7100/SP9200, use by connecting to Vector interface or similar product,

Non-Contact CAN Sensor SP7002-90 CAN support,

bundle including SP7002/SP7100/SP9200, use by connecting to Vector interface or similar

Case



CARRYING CASE C1010 For the MR6000, hard trunk type, for storing options

Input modules

HIGH SPEED ANALOG UNIT U8976 2 ch, voltage input, 200 MS/s, (DC to 30 MHz) **ANALOG UNIT 8966**

2 ch, voltage input, 20 MS/s, (DC to 5 MHz)

4CH ANALOG UNIT U8975 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), Input voltage limit: 200 V DC

4CH ANALOG UNIT U8978 4 ch, voltage input, 5 MS/s, (DC to 2 MHz), highest sensitivity range 100 mV f.s.

HIGH RESOLUTION UNIT 8968 2 ch, voltage input, 1 MS/s (DC to 100 kHz)

DC/RMS UNIT 8972

2 ch, voltage/1 MS/s, (DC to 400 kHz) RMS rectifier (DC, 30 to 100 kHz)

HIGH-VOLTAGE UNIT U8974

2 ch, voltage input, max. 1000 V DC and 700 V AC

DIGITAL VOLTMETER UNIT MR8990 2 ch, high-precision DC voltage, 0.1 µV resolution,

maximum sampling rate 500 times/s

3CH CURRENT UNIT U8977

3 ch, for measuring current using dedicated current sensors, can be directly connected to ME15W (12-pin) connector-type sensors, for use with up to 3 units

CURRENT UNIT 8971

2 ch, for measuring current using dedicated current sensors, 2 CONVERSION CABLES 9318 included, for use with up to 4 units

TEMP UNIT 8967

2 ch, thermocouple temperature input

STRAIN UNIT U8969

2 ch, strain gauge type converter amp

CONVERSION CABLE L9769 (for STRAIN UNIT U8969 only, included)

FREQ UNIT 8970

2 ch, for measurement of frequency, RPM, pulse, etc.

CHARGE UNIT U8979 2 ch, for acceleration measurement, supports charge output, pre-amp output (IEPE type), and voltage output

LOGIC UNIT 8973

4 terminals, 16 ch, installable in all 8 slots

Output modules * Input cords not included. Please purchase separately



ARBITRARY WAVEFORM GENERATOR UNIT U8793 2 ch, 10 mHz to 100kHz FG, -10 V to 15 V output, D/A refresh rate (arbitrary waveform generator mode): 2 MHz

WAVEFORM GENERATOR UNIT MR8790

PULSE GENERATOR UNIT MR8791 8 ch, 0.1 Hz to 20 kHz pulse output, pattern output

Logic signal measurement



LOGIC PROBE 9327 LOGIC PROBE 9320-01

4-channel type, for voltage/contact signal ON/OFF detection Not isolated Response pulse width: 500 ns or more (9320-01), 100 ns or more (9327) Digital input threshold: 1.4 V / 2.5 V / 4.0 V Maximum input voltage: 0 to +50 V DC

Logic Probe MR9321-01

4 channels, ON/OFF detection of AC/DC voltage

Isolated
Response time: rising, 1 ms or less; falling, 3 ms or less
Output (H) detection: 170 to 250 V AC, ±(70 to 250) V DC (HIGH range)
60 to 150 V AC, ±(20 to 150) V DC (LOW range)
Output (L) detection: 0 to 30 V AC, ±(0 to 43) V DC (HIGH range)
0 to 10 V AC, ±(0 to 15) V DC (LOW range)
Maximum input voltage: 250 Vrms (HIGH range), 150 Vrms (LOW range)

External sampling measurement



CONNECTION CABLE L9795-01 Max. rated voltage to ground: 33 V AC rr SMB terminal to alligator clip, 1.5 m (4.92 ft.)

CONNECTION CABLE L9795-02

Max. rated voltage to ground: 33 V AC rms or 70 V DC, SMB terminal to BNC terminal, 1.5 m (4.92 ft.)

PC Software



Software that provides operability similar to the MR6000, allowing you to load measurement data, display waveforms, and perform calculation ..Free download


MR6000 Viewer



WAVE PROCESSOR 9335 PC display for massive amounts of waveform data and more LAN CABLE 9642

Straight Ethernet cable, supplied with straight to cross conversion cable, 5 m (16.41 ft.) length

For details, see product information on Hioki's website.



BUS BAR CLIP L4936

GRABBER CLIP L9243

INPUT CORD (G) *For the MR8990 *Voltage is limited to to specifications of the input modules in the specifications of the input modules in the specific at the

TEST LEAD L2200

600 V. CAT III 1000 V

MAGNETIC ADAPTER L4937

600 V


Attach to the tip of banana plug cables, CAT III

Attach to the tip of banana plug cables, CAT III


Attaches to the tip of banana plug cables, red/black set, full length: 185 mm (7.28 in.), CAT II 1000 V


Cable length: 70 cm (2.30 ft.), tips interchangeable with a pin test lead or


alligator clip, maximum input voltage: CAT IV











form, and total RMS output CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, 1.6 m (5.25 ft.) length

SENSOR UNIT CT9555

SENSOR UNIT CT9556 1ch, with waveform and RMS

SENSOR UNIT CT9557

4ch, with waveform, total wave

CONVERSION CABLE CT9901 Convert ME15W (12-pin) terminal to PL23 (10-pin) terminal

High sensitivity, wideband 'Requires Probe Power current measurement Unit Z5021.

CURRENT PROBE CT6710 Frequency characteristics: DC to 50 MHz wideband response, 0.5 A-class up to 30 Arms

CURRENT PROBE CT6711 Frequency characteristics: DC to 120 MHz

CURRENT PROBE CT6700

CURRENT PROBE CT6701

CLAMP ON PROBE 3273-50

CLAMP ON PROBE 3276

CLAMP ON PROBE 3274 Frequency characteristics: DC to 10 MHz wideband response, up to 150 Arms

CLAMP ON PROBE 3275 Frequency characteristics: DC to 2 MHz

wideband response, up to 500 Arms

wideband response, 0.5 A-class up to 30 Arms

Frequency characteristics: DC to 50 MHz wideband response, 1 mA-class up to 5 Arms

Frequency characteristics: DC to 120 MHz wideband response, 1 mA-class up to 5 Arms

Frequency characteristics: DC to 50 MHz wideband response, 10 mA-class up to 30 Arms

Frequency characteristics: DC to 100 MHz wideband response, 10 mA-class up to 30 Arms

010



Convert PL23 (10-pin) terminal to ME15W (12-pin) terminal

CONVERSION CABLE CT9900

Custom cable For P9000. Inquire with your local Hioki distributor.

(1) Bus powered USB cable (2) USB(A)- Micro B cable (3) 3-prong cable

Non-contact voltage measuring

NON-CONTACT AC VOLTAGE PROBE SP3000-01 5 V rms rated, 10 Hz to 100 kHz band width NON-CONTACT AC VOLTAGE PROBE SP3000 Sold individually

AC VOLTAGE PROBE SP9001 Sold individually

Other options for input

CONNECTION CORD L9217 Cord has insulated BNC connectors at both ends, signal output use, 1.6 m (5.25 ft.) length CONVERSION ADAPTER 9199 Receiving side banana terminal, output BNC terminal


Temperature sensor



THERMOCOUPLE *For reference only. Please purchase locally

INPUT CABLE (H)





*The bandwidth of current sensors and current probes is limited by the bandwidth of the current unit to be connected

*Depending on the combination of current sensors and current probes, physical and space limitations may prevent simultaneous connection. Hioki can assist with special order conversion cables - please inquire with your local distributor.

*A total of 9 current sensors and current probes can be connected simultaneously to the Memory HiCorder. However, when using the CT6710 or CT6711, a total of 4 probes can be connected. (Total with the CURRENT UNIT US977, CURRENT UNIT 8971, and PROBE POWER UNIT Z5021 connected)

*Three U8977 current units and four 8971 current units can be simultaneously connected to the Memory HiCorder.

'If combining a current sensor or current probe with a sensor power source and using the voltage input analog unit for current measurement, there is no limitation on the number of connections.

*Only the U8977 can use the CT9920 to convert a PL14 connector sensor. The 8971 does not support this combination.



DISTRAME - Tél.: 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr


R&D testing and analysis Meeting the demanding requirements of a broad range of industries



















We have drastically improved the technology used in our Memory HiCorders, developing the MR6000 Memory HiCorder to meet the advanced demands of all industries.

Unit selection guide (18 types)

Unit interchangeability

The following units are compatible with the MR6000. Some units in the list are also compatible with the MEMORY HiCORDER MR8827, MR8847A, MR8740, MR8741, and MR8740-50. Please check the brochure of each product.

Measurement Units												
Measured signal	Model	Description	No. of channels	Fastest sampling	Bandwidth	A/D resolution	DC accuracy	Max. input voltage	Sensitivity (#1)	Max. sensitivity range	Isolation	Supplement
Voltage (high speed)	U8976	High-Speed Analog Unit	2 ch	200 MS/s	DC to 30 MHz	12 bits	±0.5% f.s.	400 V DC 1000 V DC (#2)	0.0625 mV	100 mV f.s.	Yes	n/a
Voltage	8966	Analog Unit	2 ch	20 MS/s	DC to 5 MHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	n/a
Voltage (4ch)	U8975	4ch Analog Unit	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.1% f.s.	200 V DC	0.125 mV	4 V f.s.	Yes	n/a
Voltage (4ch, high resolution)	U8978	4ch Analog Unit	4 ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	40 V DC	3.125 uV	100 mV f.s.	Yes	n/a
Voltage (high resolution)	8968	High Resolution Unit	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.3% f.s.	400 V DC	3.125 uV	100 mV f.s.	Yes	with AAF
Voltage (DC, RMS)	8972	DC/RMS Unit	2 ch	1 MS/s	DC to 400 kHz	12 bits	±0.5% f.s.	400 V DC	0.05 mV	100 mV f.s.	Yes	with RMS
Voltage (high voltage)	U8974	High Voltage Unit	2 ch	1 MS/s	DC to 100 kHz	16 bits	±0.25% f.s.	1000 V DC 700 V AC	0.125 mV	4 V f.s.	Yes	n/a
Voltage (high resolution)	MR8990	Digital Voltmeter Unit	2 ch	2 ms	n/a	24 bits	±0.01% rdg. ±0.0025% f.s.	500 V DC	0.1 uV	100 mV f.s.	Yes	n/a
Current	U8977	3ch Current Unit	3ch	5 MS/s	DC to 2 MHz	16 bits	±0.3% f.s.	Current sensor only		on current nsor	n/a	Max. 3 Units
Current	8971	Current Unit	2 ch	1 MS/s	DC to 100 kHz	12 bits	±0.65% f.s.	Current sensor only	-	on current nsor	n/a	with RMS Max. 4 Units
Temperature	8967	Temperature Unit	2 ch	1.2 ms	DC	16 bits	Detailed reference	Thermocouples only	0.01°C	200°C (392°F)f.s.	Yes	n/a
Strain	U8969	Strain Unit	2 ch	200 kS/s	DC to 20 kHz	16 bits	±0.5% f.s. ±4 με	Strain only	0.016 με	400 μεf.s.	Yes	Discontinued product 8969 can also be used
Frequency	8970	Frequency Unit	2 ch	200 kS/s	DC to 100 kHz (#3)	16 bits	n/a	400 V DC	0.002 Hz	Depends on mode	Yes	n/a
Acceleration	U8979	Charge Unit	2 ch	200 kS/s	DC to 50 kHz (DC) 1 Hz to 50 kHz (AC)	16 bits	±0.5% f.s. (Voltage) ±2.0% f.s. (Acceleration)	40 V DC		nds on tion sensor	Yes	Supports TEDS
Logic	8973	Logic Unit	4 probes (16 ch)	n/a	n/a	n/a	n/a	n/a	n/a	n/a	n/a	Requires 9320-01, 9327 or MR9321-0

(#1) Minimum resolution shows the highest sensitivity resolution. (#2) When using the 9665 (#3) Minimum pulse width 2 µs

Output signal	Model	Description	No. of channels	Output function	Output voltage range	Supplement
Waveform generation	U8793	Arbitrary Waveform Generator Unit	2 ch	FG: Sine, Square, Pulse, Triangle, Ramp, DC Arbitrary waveform generation: Measurement waveform with Memory HiCorder, Waveform editted with the SP8000	-10 to 15 V	n/a
Waveform generation	MR8790	Waveform Generator Unit	4 ch	DC, Sine wave (output frequency range: 1 Hz to 20 kHz)	-10 to 10 V	n/a
Pulse generation	MR8791	Pulse Generator Unit	8 ch	Pulse output: frequency is 0.1 Hz to 20 kHz Logic output: output voltage level is 0 V to 5 V, Open collector output	Output terminal Connector: D-sub, half-pitch, 50-pin	n/a

DISTRIBUTED BY

 $Note: Company\ names\ and\ product\ names\ appearing\ in\ this\ brochure\ are\ trademarks\ or\ registered\ trademarks\ of\ various\ companies.$

HIOKI E.E. CORPORATION

Generator Units

HEADQUARTERS

81 Koizumi, Ueda, Nagano 386-1192 Japan https://www.hioki.com/



DISTRAME

Parc du Grand Troyes - 40 rue de Vienne - 10300 SAINTE-SAVINE Tél. : 03 25 71 25 83 - infos@distrame.fr - www.distrame.fr