

## TPS2PWR1

# Power Measurement and Analysis Software

Click image to enlarge

#### **Features & Benefits**

- Improve efficiency of power designs with switching loss measurements including turn-on, turn-off and conduction losses
- Reduce test time with harmonic measurements to the 50<sup>th</sup> harmonic
- Eliminate manual calculations with automated power analysis, waveform analysis and phase analysis with true power, reactive power, power factor, crest factor, phase relationships
- Reduce measurement time with dv/dt and di/dt cursors

## **Applications**

- Motor drive design and test
- UPS design and test
- Power semiconductor characterization
- Power quality equipment design and test
- Power monitoring and performance verification

#### **Power Measurement and Analysis Software**

As an industrial power designer or technician, you must perform a range of power-specific measurements to develop, test, and race products to market. The TPS2000 Series oscilloscopes, when equipped with TPS2PWR1 power measurement and analysis software, allows you to optimize your productivity by reducing your development and test time with a broad range of power-specific measurements, such as switching loss (including turn-on, turn-off, and conduction losses), harmonic distortion measurements to the 50<sup>th</sup> harmonic, and dv/dt and di/dt cursor measurements. Use a single instrument to make an array of measurements – from measuring high voltages\*<sup>1</sup> and high currents to debugging control circuits.

To improve the efficiency of industrial power designs, you must analyze power dissipation and characterize transitions at higher switching frequencies. Using TPS2PWR1's unique switching loss feature, you can measure switching device power dissipation with the touch of a button. Coupled with the TPS2000 Series oscilloscopes' unique digital real-time (DRT) sampling technology, the TPS2PWR1 software package enables you to efficiently and accurately characterize industrial power systems by measuring power loss at the switching device.

Reduce your development and testing time by using TPS2PWR1's harmonic testing capability to the 50<sup>th</sup> harmonic to test power supply designs to these standards from your bench, the power lab, or on-site.

In addition, TPS2PWR1 software enables you to set units and scale factor for Tektronix current and voltage probes to read the result in the right unit.

 $^{*1}$  To make floating measurements greater than 30 V<sub>RMS</sub>, use the optional P5120 passive, high-voltage probe or similarly rated passive, high-voltage probe, or an appropriately rated high-voltage, differential probe, subject to the ratings of such high-voltage probe.

## **Characteristics**

**Power Measurements -** True real power in watts, reactive power in VAR, power factor, crest factor, rms measurements, frequency measurements

Cursors - dv/dt and di/dt

**Phase angles -** CH1 & CH2, CH2 & CH3 (four channel scopes only), CH1 & CH3 (four channel scopes only)

**Harmonics measurements -** Up to the 50<sup>th</sup> harmonic, THD, individual harmonic levels display, individual harmonic phase to fundamental, rms values.

**Switching loss measurements -** Turn-on loss, turn-off loss, conduction loss, total switch loss

## **Tektronix Oscilloscopes and Probes Supported**

TPS2000 Series oscilloscopes - TPS2012, TPS2014, TPS2024

#### **Current Probes**

A621, A622, TCP202 with 1103 power supply, TCPA300 with TCP312, TCP305, TCP303, TCPA400 with TCP404XL, P6021, P6022, CT2, CT4 with TCP202 and 1103 power supply.

#### **Passive Voltage Probes**

**P2220 -** 200 MHz, 1X/10X switchable passive probe.

**P5120 -** passive high-voltage probe (1000 V CAT II tip to ground; 600 V CAT II reference to earth ground).

## **Passive High Voltage Probes**

#### **Differential Probes**

**P5200 -** high-voltage active differential probe (1300  $V_{pk-pk'}$  25 MHz).

**P5205 -** high-voltage active differential probe (1300  $V_{pk-pk'}$ , 100 MHz) (1103 power supply required).

**P5210 -** high-voltage active differential probe (5600  $V_{pk-pk'}$ , 50 MHz) (1103 power supply required).

## **Ordering Information**

## **TPS2PWR1**

Power Measurement and Analysis Software

## **TPS2PBND**

Power bundle for TPS2000 Series oscilloscopes. Includes (4) P5120 probes and TPS2PWR1 power measurement and analysis software.